

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

FEB 24 1992

O. C. D.
ARTESIA OFFICE

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

NM 56426

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Sivley Federal #2

9. API Well No.

30-0152277000

10. Field and Pool, or Exploratory Area

E. Palmillo Bone Spring

11. County or Parish, State

Eddy, New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Hondo Drilling Company

3. Address and Telephone No.

P.O. Drawer 2516 Midland, TX 79702-2516 (915) 682-9401

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1,980' FNL & 1,980' FEL, Unit G
Sec. 30 T-18-S, R-29-E

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☐ Notice of Intent

☐ Subsequent Report

☒ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plug and abandon Sivley Federal #2, Waiting on plugging unit

1. Pull 2 3/8" tubing and rods out of hole.

2. Set cast iron bridge plug in 5 1/2" casing at 6,500'. Dump 35' cement on top of bridge plug.

3. Free point 5 1/2" casing, jet cut 5 1/2" casing at 5,600'. Pull casing out of hole.

4. Spot 150' cement plug in and out of 5 1/2" casing. Tag cement plug. Spot 100' cement plug in and out of 8 5/8" casing, set at 3,015' cement circulated with 1,600 sacks. Tag cement plug.

5. Spot 100' cement plug at 400'.

6. 50' surface plug top 8 5/8" casing and set 4 1/2" abandonment marker.

Post ID-2
3-13-92
PFA

14. I hereby certify that the foregoing is true and correct

Signed

[Signature]

Title President

Date 2/10/92

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date

2/14/92