

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	<input checked="" type="checkbox"/>
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

RECEIVED BY P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

JUL 14 1986

O. C. D.
ARTESIA, OFFICE

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
E-1286

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Sol West III	8. Farm or Lease Name Turkey Track Com
3. Address of Operator P. O. Box 10151, El Paso, Texas 79992	9. Well No. 1
4. Location of Well UNIT LETTER I 660 FEET FROM THE East LINE AND 1980 FEET FROM THE South LINE, SECTION 26 TOWNSHIP 18-S RANGE 28-E NMPM.	10. Field and Pool, or Wildcat Undesignated Morrow Gas
15. Elevation (Show whether DF, RT, GR, etc.) 3459.9' GL	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER Attempt San Andres completion <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1.) Rig up and pull out of hole with tubing, RBP and packer.
- 2.) Set CIBP with 35' cement on top at 10,450' - 10,550' Morrow covered.
- 3.) Set CIBP with 35' cement on top at 8920' - 9020' Penn covered.
- 4.) Set 100' (25 sacks+) cement plug at 8350' to 8450' Wolfcamp covered.
- 5.) Pull out of hole (after free-point) 5-1/2" casing. Lay down estimated 7400' free point and cut.
- 6.) Set 100' (25 sacks+) cement plug at stub 50' in and 50' out (7350' - 7450' plus or minus) tag.
- 7.) Set 100' (25 sacks +) cement plug at 8-5/8" casing shoe (3300') spot at 3250' - 3350' Tag.
- 8.) Perforate 8-5/8" casing at (2500' - 3000' plus or minus) for a San Andres completion attempt.

NOTE: A 9.5# salt water mud will be pumped between each plug.

Notify N.M.O.C.C. in sufficient time to witness

SETTING OF CIBP @ 10,450'

Mike Williams (505) 748-1283

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED James Williams TITLE Agent DATE July 9, 1986

APPROVED BY Les A. Clements TITLE Supervisor District II DATE JUL 17 1986

CONDITIONS OF APPROVAL, IF ANY: