

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-015-25361
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 06-1409
7. Lease Name or Unit Agreement Name State "CG".
8. Well No. 1
9. Pool name or Wildcat N. Illinois Camp Morrow
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3597' GR

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Mewbourne Oil Company
3. Address of Operator P.O. Box 5270 Hobbs, New Mexico 88241	4. Well Location Unit Letter J : 2310 Feet From The East Line and 1980 Feet From The South Line Section 7 Township 18S Range 28E NMPM Eddy County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER: <input type="checkbox"/>	OTHER: <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU pulling unit. Set CIBP @ 10,150' cap with 35' cement. Load hole with 25#/bbl. salt gel and brine. Set 100' cement plugs at 7050' and 6200'. Recover as much 5-1/2" as possible. Set 100' plugs at 3900', 2885' 1050' and 418'. Set 10 sx. surface plug. Set dry hole marker, cut anchors and clean location. Will notify OCD 24 hours before starting.

Tag

100' plug in  
and out of sub.  
Tag

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rob Jones TITLE Engineer DATE Nov. 27, 1995  
(505)  
TELEPHONE NO. 393-5905

(This space for State Use)

APPROVED BY ORIGINAL SIGNED BY TIM W. GUM TITLE DISTRICT II SUPERVISOR DATE NOV 28 1995  
CONDITIONS OF APPROVAL IF ANY: