

Form 3160-5 (November 1994)

UNITED STATES DEPARTMENT OF THE INTERIOR

Oil Cons N.M. DIV-Dist. 2

FORM APPROVED

1301 W. Grand Avenue OMB No. 1004-0135 Expires July 31, 1996 BUREAU OF LAND MANAGEMENT Artesia, NM 88210 e Serial No. SUNDRY NOTICES AND REPORTS ON WELLS NM 33437A Do not use this form for proposals to drill or to re-enter an 6. If Indian, Allottee or Tribe Name abandoned well. Use Form 3160-3 (APD) for such proposals. N/A 7. If Unit or CA/Agreement, Name and/or No. SUBMIT IN TRIPLICATE - Other instructions on reverse side N/A Type of Well 🔀 Oil Well 🚨 Gas Well 🚨 Other Well Name and No. Sand 7 Federal#3 2. Name of Operator API Well No. Mitchell Energy Company L.P. 30 015 26141 3b. Phone No. (include area code) P. O. Box 4000 3a. Address 10. Field and Pool, or Exploratory Area (713)The Woodlands, TX Location of Well (Footage, Sec., T., R., M., or Survey Description) Shugart, N. (Bone Springs) 11. County or Parish, State 692' FWL & 330' FNL of Sec. 7, T18S, Eddy County, New Mexico R31E (Unit LTR D) 12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF ACTION TYPE OF SUBMISSION Production (Start/Resume) ☐ Water Shut-Off Acidize Deepen Deepen Notice of Intent Well Integrity Alter Casing Fracture Treat Reclamation Subsequent Report Other New Construction Recomplete Casing Repair ☐ Change Plans Temporarily Abandon Plug and Abandon ☐ Final Abandonment Notice ☐ Convert to Injection Plug Back Water Disposal 13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.) Unseat RHBC pump and POOH with rods & pump. Release TA and POO with 2-7/8" tbg and anchor. Set CIBP at 8030' with 35' cement on top. Displace hole with 9.5 ppg mud. RU casing jacks. Establish free point, cut 5-1/2" 17# casing at 2500' ± and POOH laying down casing. Displace hole with 9.5 ppg mud. RIH with tubing string and spot cement plug from 2591' to 50' above top of 5-1/2" casing. PU and spot 100' cement plug 532-432'. POOH with tubing and spot 5 sxs surface plug in 5-1/2" casing. Cut casing at base of cellar or 3' below ground level. Weld on P&A marker. GARY GOURLEY 14. I hereby certify that the foregoing is true and correct PETROLEUM ENGINEER Title Name (Printed/Typed) Senior Regulatory Affairs Analyst George Mullen Signature 08-15-01 THIS SPACE FOR FEDERAL OR STATE OFFICE USE Date Title Approved by

Office

Conditions of approval, if any, are attached. Approval of this notice does not warrant or

certify that the applicant holds legal or equitable title to those rights in the subject lease

which would entitle the applicant to conduct operations thereon.

PURELL OFFICE AND STATE OF TO A SOUTH OF THE STATE OF THE