

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

MAR 2 1994

WELL API NO.  
30-051-02331

5. Indicate Type of Lease  
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
B-5073

7. Lease Name or Unit Agreement Name

STATE "A"

8. Well No.

1

9. Pool name or Wildcat  
Winchester Wolfcamp

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
Oil Well ☐ GAS WELL ☒ OTHER

2. Name of Operator  
Billy R. Wilson ✓

3. Address of Operator  
112 W. Tanglewood, New Braunfels, TX 78130

4. Well Location  
Unit Letter M : 660 Feet From The South Line and 660 Feet From The West Line

Section 36 Township 19 S Range 28 E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
3286 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set CIBP at 8975 in 5-1/2" casing. Spot 35' Class H Cement over CIBP. Cut 5-1/2" casing at ±7000 and pull same. TIH with 2-3/8 tubing open ended and circulate 100' cement plug at 7050-6950. Tag plug. Circulate hole full with 9.5# ppg mud. Set 100' plugs at 4035-3935, 3085-2985. Pull 1452' 8-5/8 32# casing out of hole. Circulate 100' cement plug at 800-700" and 381-281 at shoe of 13-5/8 casing. Place 10 Sac Plug at surface. Cut surface casing at 3' below ground level. Weld on steel plate and marker and backfill.

Work to begin on or about March 10, 1994 and will require approximately three day to complete.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Billy R. Wilson*

TITLE

Operator

DATE

2/23/94  
(210)

TYPE OR PRINT NAME

BILLY R. WILSON

TELEPHONE NO. 625-1200

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: