

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

LC-029388-A

CSJS

6. If Indian, Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

William A. & Edward R. Hudson (505)676-2266

3. Address and Telephone No.

P.O. Box 9 Maljamar, New Mexico 88264

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660 FSL 1980 FWL
Sec. 10 T-18-S R-31-E Unit Letter N

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Shugart "A" #1

9. API Well No.

30-015-05509

10. Field and Pool, or Exploratory Area

Shugart

11. County or Parish, State

Eddy, N.M.

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Set 5 1/2 C.I.B.P. at 3250' cap 35' Cement or spot 25 sacks of cement. Plug across perforation at 3285' and tag.
- 2) Load Hole W/Mud
- 3) Perforate 5 1/2 casing at base of salt 1920' squeeze W/50 sacks of cement leaving 100' cement inside casing W.O.C. and tag.
- 4) Perforate 5 1/2 casing at top of salt 840' squeeze W/50 sacks of cement leaving 100' cement inside casing W.O.C. tag. This plug will also cover the 8 5/8 shoe at 743'
- 5) Perforate 5 1/2 casing and 8 5/8 casing at 60' circulate cement between 5 1/2 & 8 5/8 between 5 5/8 casing open hole leaving 5 1/2 casing full of cement. Set P.A. marker restore location.

RECEIVED

MAR 21 1995

OIL CON. DIV.
DIST. 2

I hereby certify that the foregoing is true and correct

Signed

J.B. Smith

Title

Prod. Supt.

Date

3/15/95

(This space for Federal or State office use)

Orig. Signed by Shannon J. Shaw

Approved by

Conditions of approval, if any:

Title

PETROLEUM ENGINEER

Date

3/15/95