

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPlicate  
(Other instructions on reverse side)

Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-029388-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Shugart "A"

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Shugart Y-SF-2-G

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 10-18S-31E

12. COUNTY OR PARISH 13. STATE

Eddy N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT-" for such proposals.)

OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection RECEIVED

2. NAME OF OPERATOR

William A. & Edward R. Hudson

3. ADDRESS OF OPERATOR

P.O. Box 9, Maljamar, New Mexico 88264

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)

AT SURFACE

1980' from North and East lines,  
Sec. 10-18S-31E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3731 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON\*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

We propose to permanently plug and abandon this well as follows:

Set a "cast iron" bridge plug at 3200', spot 35' cement on top of plug, fill hole with salt gel mud, spot 100' cement from 1997' to 1897', perforate 5-1/2" casing at 750', set cement retainer at 700', circulate cement to the surface, fill hole with fresh water, place 150' cement on top of the retainer, place 60' cement at the surface.

Install a 4" x 8' dry hole marker with well data, clean location of all debris, restore surface to BLM regulations.

Notify BLM at 887-6544 and NMOCDC at 748-1283 prior to commencing P & A operations.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Prod. Supt.

DATE 8/9/89

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

FOR:

TITLE CHIEF, MINERAL RESOURCES

DATE

8-17-89

\*See Instructions on Reverse Side

WILLIAM A. & EDWARD R. HUDSON  
SHUGART "A" NO. 3

SKETCH

