

Form 1000  
(May 1965)UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSTAMP IN TRIPLICATE\*  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.  
5. LEASE DESIGNATION AND SERIAL NO.

LC 047633(a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

\*E.H. Swearingen "A"

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Shugart

11. SEC., T., R., W., OR SECT. AND  
SURVEY OR AREA

Sec. 14, T-18S, R-31E

12. COUNTY OR PARISH 13. STATE

Bddy

N.M.

1. OIL ☐ GAS ☐ OTHER ☐ WIW - (T.A.)

2. NAME OF OPERATOR

Atlantic Richfield Company ✓

3. ADDRESS OF OPERATOR

P. O. Box 1978, Roswell, New Mexico 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

660' FNL &amp; 1980' FEL (Unit Letter B)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, WT, GA, etc.)

3735' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☒CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐(Note: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

This injection well was temporarily abandoned on 2/13/67 due to low water injectivity. We now propose to P & A as follows:

Set 30 sk cement plug in and out of 7" shoe at 3230'. Shoot off and recover 7" casing from free point. Spot these cement plugs: 30 sx in and out of 7" stub; 30 sx across 8-5/8" shoe @ 900', and 10 sx in top of well. 8-5/8" casing will remain intact. Salt gel mud will be used to spot all cement plugs. Dry hole marker will be installed and location cleared and levelled.

RECEIVED

MAY 27 1970

U. S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Dist. Drlg. Supervisor DATE 5/26/70

(This space for Federal or State office use)

APPROVED

CONDITIONS OF APPROVAL, IF ANY:

MAY 27 1970  
R. L. BEEKMA  
ACTING DISTRICT SUPERVISOR

TITLE

RECEIVED

DATE

MAY 28 1970

O. C. C.  
ARTESIA, OFFICE

\*See Instructions on Reverse Side