

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN 1 ICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 068535 A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Honda

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Dagger Draw (Upper Penn)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 31, T-19S, R-25E

12. COUNTY OR PARISH

Eddy

New

Mexico

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

Monsanto Company

3. ADDRESS OF OPERATOR

101 N. Marienfeld, Midland, Texas

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' FWL & 660' FNL, Section 31, T-19S, R-25E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3568 RT

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data.

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☒	WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒	SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
REPAIR WELL ☐	CHANGE PLANS ☐	(Other) ☐	(Other) ☐

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Due to non-commercial production, this well is to be plugged and abandoned. 5 1/4" casing on this well is set @ 7898' & cmt'd. back to 6700'. Subsequent squeeze cementing puts the top of cmt. @ 5700'. Present plug back total depth (w/cmt) is 7780' & perforations are now open @ 7766', 7759 1/2' & 7621'.

Plugging procedures will be as follows:

- 1.) Spot 25 sx cmt. plug from 7780' to 7492'
- 2.) Load casing w/mud
- 3.) Shoot casing off @ approximately 5100' & pull same
- 4.) Run tbg. & spot plugs as follows:

5150'-5050' w/23 sx (50' in & out of 5 1/4")
3700'-3600' w/23 sx (Bone Spring Porosity)
2250'-2150' w/23 sx (T/Glorietta @ 2200')
1450'-1350' w/26 sx (50' in & out of 9-5/8")
20'-0' w/6 sx

- 5.) Install 4" x 5' permanent marker & clean location.

Verbal approval for foregoing procedure obtained from Mr. J. A. Knauf via telephone on 11-17-65 by Mr. C. K. Reeves. Plugging operations will begin 11-19-65.

18. I hereby certify that the foregoing is true and correct

SIGNED

(This space for Federal or State office use)

TITLE District Engineer

DATE 11-17-65

APPROVED BY
CONDITIONS OF APPROVAL IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.