

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

NM OIL CONS COMMISSION

Drawer **DD**  
FORM APPROVED  
Bureau Bulletin No. 88-210  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT —" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well <input type="checkbox"/> Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other	7. If Unit or CA, Agreement Designation
2. Name of Operator YATES PETROLEUM CORPORATION (505) 748-1471	8. Well Name and No. Bluffsides WF Federal #1
3. Address and Telephone No. 105 South 4th St., Artesia, NM 88210	9. API Well No. 30-015-24348
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 1980' FNL & 660' FWL of Section 9-T19S-R27E	10. Field and Pool, or Exploratory Area Angell Ranch Atoka Morrow
	11. County or Parish, State Eddy Co., NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Propose to plug and abandon well as follows:

1. Retrieve RBP at 8830' and Uni VI packer at 10120'.
2. Set CIBP at 9875' and cap with 35' of cement.
3. Set CIBP at 8710' and cap with 35' of cement.
4. Cut and pull 4-1/2" casing. CBL indicated top of cement at 8080'.
5. Set a 100' cement plug across the top of the 4-1/2" casing stub. WOC. Tag plug.
6. Set a 100' cement plug across 5080-4950'.
7. Set a 100' cement plug across the 8-5/8" casing shoe (2034-1934'). WOC. Tag plug.
8. Set a 100' cement plug across the 13-3/8" casing shoe (445-345'). WOC. Tag plug.
9. Set a 50' cement plug at the surface.
10. Install regulation abandonment marker.

NOTIFY BLM-CARLSBAD (505-887-6544) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS

NOTE: Rex Gates, engineer with Yates Petroleum Corporation received verbal permission from Joe Lara w/BLM-Carlsbad on September 8, 1995, to plug well as indicated above.

14. I hereby certify that the foregoing is true and correct

Signed Rex Gates Title Production Clerk Date Sept. 8, 1995

(This space for BLM or State office use)

Approved by (ORIG. SCD.) JOE G. LARA Title PETROLEUM ENGINEER Date 9/15/95

Conditions of approval, if any: See attached.