

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

# OIL CONSERVATION DIVISION

P.O. Box 2088

Santa Fe, New Mexico 87504-2088

WELL API NO.

30-015-25337

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

LG-6459

7. Lease Name or Unit Agreement Name

Agave AAJ State

8. Well No.

2

9. Pool name or Wildcat

Undesignated Abo

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL  
WELL ☐

GAS  
WELL ☒

OTHER

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address of Operator

105 South Fourth Street - Artesia, NM 88210

4. Well Location

Unit Letter K : 1980 Feet From The South Line and 1980 Feet From The West Line

Section 32

Township 19S

Range 24E

NMPM

Eddy

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3826' GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: Temporarily Abandon Upper Penn & recomplete to Abo ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to temporarily abandon Upper Penn completion 6307-7538' and recomplete to Abo 4052-4080' as follows:

1. Nipple down tree and nipple up BOP. POOH with tubing and packer.
2. Set RBP at 6250'± to temporarily abandon Upper Penn 6307-7538'. NOTE: Will want to go back to this zone and deplete reserves some day.
3. Pressure test casing to 500 psi.
4. Run CBL & cement evaluation tool.
5. RIH w/3-1/8" casing gun and perforate 4052-4080' w/57 holes (2 SPF) (Abo Dolomite).
6. RIH w/RBP and treating packer on 2-7/8" workstring. Set RBP at 4110' to isolate old squeezed perfs. Set packer at 4000'±. Acidize perforations 4052-4080' w/4000 gallons 15% NEFE HCL acid and ball sealers.
7. Swab test.
8. Move packer to 3150'±. Frac perfs 4052-80' w/200000 gallons 30# crosslink gel and 330000# 20-40 Brady sand. Turn to production.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Rusty Klein*

TITLE

Production Clerk

DATE

9-23-94

TYPE OR PRINT NAME

Rusty Klein

505-748-1471  
TELEPHONE NO.

(This space for State Use)

SUPERVISOR, DISTRICT II

APPROVED BY

TITLE

DATE

SEP 23 1994