

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Robert N. Enfield

3. Address and Telephone No.

P.O. Box 2431 Santa Fe, New Mexico 87501 (505) 988-2863

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FNL and 990' FEL of Section 7

(Sec. 7, T-19-S, R-27-E)

5. Lease Designation and Serial No.

NM-29826

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Walters Federal

9. API Well No.

1

10. Field and Pool, or Exploratory Area

Undes. McMillan U. Penn

11. County or Parish, State

Eddy Co. New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Move in and rig up equipment.

POH with completion assembly.

Rig up electric line unit; run and set a CIBP @ 7,830' KB, dump 35 feet of cement on top.

Determine casing free point.

GIH with open ended tubing to cement plug (appx. 7795' KB); spot 9.5#/gal. SW gel mud.

Pull out of hole with tubing.

Cut and pull 4.50" casing (6,000± feet).

GIH hole with open ended tubing 100 feet into stub; circulate 200' cement plug (min. 25 sx.) to spot.

WOC; tag plug. Respot plug if required.

PUH to 4,000' KB, spot 60 sx. cement plug back to 3,850' KB with mud.

PUH to 2500' KB, spot 70 sx. cement plug back to 2,300' KB with mud.

WOC; tag plug. Respot plug if required.

PUH to 450' with tubing; circulate cement back to surface.

Cut off well head; install dry hole marker as required.

Clear, rip and re-seed road and location as required.

14. I hereby certify that the foregoing is true and correct

Signed James F. Enfield Title Agent Consult. Emp. Date 7/13/92

(This space for Federal or State office use)

Approved by _____ Title _____ Date 7/17/92

Conditions of approval, if any: