Submit 3 Copies to Appropriate District Office

State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

DISTRICT I P.O. Box 1980, Hobbs, NM 88240

CONDITIONS OF APPROVAL, IF ANY:

OIL CONSERVATION DIVISION

Dicember 1	20 075 05060
DISTRICT II P.O. Drawer DD, Artesia, NM 88210 Santa Fe, New Mexico 87504-2088	30-015-25863
DISTRICT III	5. Indicate Type of Lease STATE FEE X
1000 Rio Brazos Rd., Aztec, NM 87410	6. State Oil & Gas Lease No.
	013550
SUNDRY NOTICES AND REPORTS ON WELLS	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	Anderson 15
1. Type of Well:	Anderson 15
OIL GAS WELL X OTHER	
2. Name of Operator	8. Well No.
Nearburg Producing Company	1
3. Address of Operator	9. Pool name or Wildcat
P. O. Box 823085, Dallas, TX 75382-3085	Cemetary Morrow
4. Well Location	
Unit Letter H: 1755 Feet From The North Line and 66	O Feet From The East Line
Section 15 Township 20S Range 25E	Name Eddy a
10 Elevation (Show whether DF, RKB, RT, GR, etc.)	NMPM Eddy County
	<i>\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\</i>
11. Check Appropriate Box to Indicate Nature of Notice, F	eport or Other Data
	SSEQUENT REPORT OF:
NOTICE OF INTENTION TO.	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON X REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLIN	GOPNS. PLUG AND ABANDONMENT
PULL OR ALTER CASING CASING TEST AND C	EMENT JOB
OTHER: OTHER:	
12 Describe Proposed or Completed Commisses (Clarify Mark 1997)	
12 bescribe Froposed of Completed Operations (Clearly state all pertinent delaus, and give pertinent dates, inch	ding estimated date of starting any proposed
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incluwork) SEE RULE 1103.	
work) SEE RULE 1103.	
work) SEE RULE 1103. 1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement.	ding estimated date of starting any proposed 12) 30 SACKS FROM 1800 TO 1700
 see RULE 1103. MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. Circ hole w/25#/bbl gel mud. 	
 Work) SEE RULE 1103. MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. Circ hole w/25#/bbl gel mud. PU csg and cut @ 8975' or free point and LD. 	
work) SEE RULE 1103. 1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4-1/2" csg stub)	
 MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. Circ hole w/25#/bbl gel mud. PU csg and cut @ 8975' or free point and LD. Pump 50 sx PP cement from 9175' to 8775'. (4-1/2" csg stub) WOC f/3 hrs. RIH and tag TOC. 	
 MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. Circ hole w/25#/bbl gel mud. PU csg and cut @ 8975' or free point and LD. Pump 50 sx PP cement from 9175' to 8775'. (4-1/2" csg stub) WOC f/3 hrs. RIH and tag TOC. Pump 25 sacks Premium Plus cement from 6775' to 6675'. 	
work) SEE RULE 1103. 1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4-1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC.	
work) SEE RULE 1103. 1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4-1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC.	
1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4–1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC. 6) Pump 25 sacks Premium Plus cement from 6775' to 6675'. 7) Pump 25 sacks Premium Plus cement from 4675' to 4575'. 8) Pump 25 sacks Premium Plus cement from 2575' to 2475'.	
1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4-1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC. 6) Pump 25 sacks Premium Plus cement from 6775' to 6675'. 7) Pump 25 sacks Premium Plus cement from 4675' to 4575'. 8) Pump 26 sacks Premium Plus cement from 2575' to 2475'. OK 9) Pump 60 sacks Premium Plus cement from 1455' to 1255'.	12) 30 SACKS FROM 1800 TO 1700
1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4–1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC. 6) Pump 25 sacks Premium Plus cement from 6775' to 6675'. 7) Pump 25 sacks Premium Plus cement from 4675' to 4575'. 8) Pump 25 sacks Premium Plus cement from 2575' to 2475'. OX 9) Pump 25 sacks Premium Plus cement from 355' to 1255'.	12) 30 SACKS FROM 1800 TO 1700
1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4-1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC. 6) Pump 25 sacks Premium Plus cement from 6775' to 6675'. 7) Pump 25 sacks Premium Plus cement from 4675' to 4575'. 8) Pump 25 sacks Premium Plus cement from 2575' to 2475'. 0) 9 Pump 60 sacks Premium Plus cement from 1455' to 1255'. 7) Pump 25 sacks Premium Plus cement from 1455' to 1255'. 7) Surface plug w/10 sx PP cement. Set dry hole marker.	12) 30 SACKS FROM 1800 TO 1700
1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4–1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC. 6) Pump 25 sacks Premium Plus cement from 6775' to 6675'. 7) Pump 25 sacks Premium Plus cement from 4675' to 4575'. 8) Pump 25 sacks Premium Plus cement from 2575' to 2475'. 0) 9) Pump 25 sacks Premium Plus cement from 355' to 1255'.	12) 30 SACKS FROM 1800 TO 1700
1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4-1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC. 6) Pump 25 sacks Premium Plus cement from 6775' to 6675'. 7) Pump 25 sacks Premium Plus cement from 4675' to 4575'. 8) Pump 26 sacks Premium Plus cement from 2575' to 2475'. 10) Pump 25 sacks Premium Plus cement from 1455' to 1255'. 71 Pump 25 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 25 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 25 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 25 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 25 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 26 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 27 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 28 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 28 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 28 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 28 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 28 sacks Premium Plus cement from 1455' to 1255'. 8) Pump 28 sacks Premium Plus cement from 1455' to 1255'.	12) 30 SACKS FROM 1800 TO 1700
1) MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4-1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC. 6) Pump 25 sacks Premium Plus cement from 6775' to 6675'. 7) Pump 25 sacks Premium Plus cement from 4675' to 4575'. 8) Pump 25 sacks Premium Plus cement from 2575' to 2475'. 0)(9) Pump 25 sacks Premium Plus cement from 1455' to 1255'. 10) Pump 25 sacks Premium Plus cement from 362' to 232'. 11) Surface plug w/10 sx PP cement. Set dry hole marker.	12) 30 SACKS FROM 1800 TO 1700
MIRU plugging unit. Set CIBP @ 9475' w/ 5 sx cement. 2) Circ hole w/25#/bbl gel mud. 3) PU csg and cut @ 8975' or free point and LD. 4) Pump 50 sx PP cement from 9175' to 8775'. (4–1/2" csg stub) 5) WOC f/3 hrs. RIH and tag TOC. 6) Pump 25 sacks Premium Plus cement from 6775' to 6675'. 7) Pump 25 sacks Premium Plus cement from 4675' to 4575'. 8) Pump 25 sacks Premium Plus cement from 2575' to 2475'. OX 9) Pump 60 sacks Premium Plus cement from 1455' to 1255'. 71 Pump 25 sacks Premium Plus cement from 2575' to 2475'. OX 9) Pump 60 sacks Premium Plus cement from 352' to 252'. 11) Surface plug w/10 sx PP cement. Set dry hole marker. I hereby certify that the information above is true and complete to the best of my knowledge and belief.	12) 30 SACKS FROM 7800 TO 7700' TOC. Upt. DATE 9/20/94