

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2038
SANTA FE, NEW MEXICO 87501

MAY 14 1993

Form C-103
Revised 10-1-76

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Barber Oil, Inc.	8. Farm or Lease Name L. F. Rayroux
3. Address of Operator P. O. Box 1658 Carlsbad, NM 88221-1658 (505) 887-2566	9. Well No. 1-A
4. Location of Well UNIT LETTER H 1950 FEET FROM THE North LINE AND 630 FEET FROM THE East LINE, SECTION 24 TOWNSHIP 21S RANGE 26E N.M.P.M.	10. Field and Pool, or Wildcat Carlsbad Delaware
15. Elevation (Show whether DF, RT, GR, etc.) 3165' GR	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER AMENDED (2) <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Within 90 days of approval will MOL, rig up pulling unit, remove rods and tubing. Spot cement from T.D. @ 2670' to 2542' (128') and tag. Run free point to determine TOC on 5 1/2" casing. Will either shoot off 5 1/2" csg at about 2130' and cement across stub from 2355' to 2085' and tag OR spot 270' plug from 2355' to 2085' inside 5 1/2" (30 sxs) and move up hole to about 700' and shoot off 5 1/2" csg, spot 200' plug from 755' to 555' across stub, reef and shoe of 8-5/8" csg and tag. Spot 100' (25 SXS) inside 8-5/8" csg at 475' and tag. Fill 8-5/8" hole from 258' to surface with cement and overfill down backside of 8-5/8" csg and bring to surface. Set marker. Clean location. Plow roads, location and surface.

* WHO/REL BETWEEN ALL PLUGS

Notify N.M.O.C.C. in sufficient time to witness
PLUGGING

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED	TITLE President	DATE 5/12/93
APPROVED	TITLE Seal	DATE 5-18-93