

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-

|                        |  |
|------------------------|--|
| NO. OF COPIES RECEIVED |  |
| DISTRIBUTION           |  |
| SANTA FE               |  |
| FILE                   |  |
| U.S.G.S.               |  |
| LAND OFFICE            |  |
| OPERATOR               |  |

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. Name of Operator  
Barber Oil, Inc.

3. Address of Operator  
P. O. Box 1658 Carlsbad, NM 88221-1658 (505) 887-2566

4. Location of Well  
UNIT LETTER H 1950 FEET FROM THE North LINE AND 630 FEET FROM  
THE East LINE, SECTION 24 TOWNSHIP 21S RANGE 26E NMPM.

7. Unit Agreement Name

8. Farm or Lease Name  
L. F. Rayroux

9. Well No.  
1-A

10. Field and Pool, or Wildcat  
Carlsbad Delaware

11. Elevation (Show whether DF, RT, GR, etc.)  
3165' GR

12. County  
Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WORK ☐ ALTERING CASING ☐  
TEMPORARILY ABANDON ☐ COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
PULL OR ALTER CASING ☐ CHANGE PLANS ☐ CASING TEST AND CEMENT JOB ☐  
OTHER AMENDED (2) ☐ OTHER \_\_\_\_\_

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

Within 90 days of approval will MOL, rig up pulling unit, remove rods and tubing. Spot cement from T.D. @ 2670' to 2542' (128') and tag. Run free point to determine TOC on 5 1/2" casing. Will either shoot off 5 1/2" csg at about 2130' and cement across stub from 2355' to 2085' and tag OR spot 270' plug from 2355' to 2085' inside 5 1/2" (30 sxs) and move up hole to about 700' and shoot off 5 1/2" csg, spot 200' plug from 755' to 555' across stub, reef and shoe of 8-5/8" csg and tag. Spot 100' (25 SXS) inside 8-5/8" csg at 475' and tag. Fill 8-5/8" hole from 258' to surface with cement and overfill down backside of 8-5/8" csg and bring to surface. Set marker. Clean location. Plow roads, location and surface.

\* If 5 1/2 csg is cut around the 8-5/8 shoe, cut to 750'. Spot 75 sxs woc & tag. Want cement to come to 500'. 50ft above reef.

We do not require the surface to be plowed.

Plug mud between plugs. 25Lb gel to bbl of brine.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Michael J. [Signature] TITLE President DATE 5/12/93  
Mark [Signature] TITLE Gen DATE 5-18-93