

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN DUPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

New Mexico - 04535

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal "PA" Lease

9. WELL NO.

1-1

10. FIELD AND POOL, OR WILDCAT

Wildcat11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA**S.1: T20S: R30E: W4PM**

12. COUNTY OR PARISH

Eddy

13. STATE

N. Mex.

1.

OIL WELL ☐ GAS WELL ☐ OTHER ☒**Dry Hole**

2. NAME OF OPERATOR

John H. Trigg

3. ADDRESS OF OPERATOR

P. O. Box 106 - Maljamar, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface**660 Feet from South Line and 1980 Feet from East Line**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3426.2 DF

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETION ☒ABANDON* ☒CHANGE PLANS ☐**XXXXX**

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon this well at a total depth of 2256' as per conversation with Mr. Knauf. We set 8-5/8" casing @ 663' and circulated plus 7" casing @ 1878' with 50 sacks. The 7" casing was cut @ 1455' and removed. We plan to follow the procedure as discussed;

1. Run tubing and set 10 sack cement plug from 2256' to 2215'.
2. Set 25 sack cement plug from 2215' to 2115'.
3. Pump in 400 barrels of mud @ 2115'.
4. Set 500 sack cement plug from 1810' to 480'.
5. Fill with mud.
6. Set 10 sack cement plug from 30' to surface.
7. Erect regulation marker and clean up location.
8. All cement and mud will be mixed using brine water.

RECEIVED

DEC 2 1964

FEDERAL BUREAU OF
GEOLOGICAL SURVEY

18. I hereby certify that the foregoing is true and correct

SIGNED

Joseph E. Aston

TITLE

Production Clerk

DATE

November 27, 1964

(This space for Federal or State office use)

APPROVED BY

CONTRIBUTION TO APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.