

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION

P.O. Box 2088

Santa Fe, New Mexico 87504-2088

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.
30-015-20138

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
L-185

7. Lease Name or Unit Agreement Name
Mahun State

8. Well No.
1

9. Pool name or Wildcat
Rocky Arroyo WFC

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE 'APPLICATION FOR PERMIT' (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☐ GAS WELL ☒ OTHER ☐

2. Name of Operator
CARL A. SCHELLINGER

3. Address of Operator
P. O. Box 447, Roswell, NM 88202-0447

4. Well Location
Unit Letter F : 1800 Feet From The North Line and 1980 Feet From The West Line
Section 16 Township 22 South Range 22 East NMPM EDDY County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
4347 GL

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐		CASING TEST AND CEMENT JOB ☐	
OTHER: ☐		OTHER: ☐	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) RU. TOH w/ Pka, RU. Wire-line, TIH w/ CIBP (4 1/2") Set At 6410'
- 2) TOH w/ Wire-line, TIH w/ tbs. Open-ended. Circ hole w/ SALT-GEI.
Place 30' plug on CIBP. Set Cement plug's as follows:
a) 50' plug At 6050' (Wolf camp) Perf csq @ 4858' Place 100' plug inside & outside pipe 4758 - 4858'
b) 30' plug At 3350' (Dance-strain) Perf csq @ 3350' Place 100' plug inside & outside pipe 3250 - 3350'
c) 30' plug At 1850' (B-7/8 shoe) Perf csq @ 1849' Place 50' plug outside pipe Place 100' plug in pipe 1749' - 1849' - TAG
d) 10' plug At Surface. Perf csq @ 1590' Place 100' plug inside & outside pipe 1490 - 1590'
- 3) Lay down tbs. Install day-hole marker. Cut Anchor's + Rep location
Seed location according to State SPEC's. Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE CARL A. SCHELLINGER TITLE _____ DATE 10/1/01

TYPE OR PRINT NAME Frank Morgan Agent TELEPHONE NO. _____

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep ID DATE 11-16-01

CONDITIONS OF APPROVAL, IF ANY: