

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

MAY 28 1991

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

Federal NM 0490463

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

BURTON FLAT DEEP UNIT

8. Well Name and No.

BURTON FLAT UNIT

9. API Well No.

7

10. Field and Pool, or Exploratory Area

BURTON FLAT - WOLFCAMP

11. County or Parish, State

Section 33, T-20S, R-28E

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

BHP PETROLEUM COMPANY INC.

3. Address and Telephone No.

5847 SAN FELIPE, SUITE 3600, HOUSTON, TEXAS 77057

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FSL & 660' FEL of Section 33

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other _____

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Set CIBP @9400'. Cap w/35' cement.
- 2) Freepoint 5 1/2" casing and cut (top of cement est. @ 9200' and a 100' plug (50' in, 50' out of 9 5/8") at 3000'. Tag these plugs.
- 3) Circulate hole with 9.5 ppg mud laden fluid.
- 4) Spot a 200' plug (100' in, 100' out) at 5 1/2" stub, a 100' plug at 5200' and a 100' plug (50' in, and 50' out of 9 5/8") at 3000'. Tag these plugs.
- 5) Spot a 100' plug (50' in, 50' out of 13 3/8") at 650'.
- 6) Spot a 50' surface plug.
- 7) Weld on plate and marker.

* Procedure confirmed between Shannon Shaw/BLM and Hal Crabb/BHP on 9/29/89.

14. I hereby certify that the foregoing is true and correct

Signed Scott Smith

Title Drilling/Operations Engineer

Date May 14, 1991

(This space for Federal or State office use)

Approved by _____

Conditions of approval, if any:

Title _____

Date 5/22/91

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side