

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 208
Santa Fe, New Mexico 87504-2088

FEB 21 '90

WELL API NO.

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
LG 12

SUNDRY NOTICES AND REPORTS ON WELLS. C. D.
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG OR ABANDON TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☐ GAS WELL ☒ OTHER

2. Name of Operator
Bravo Operating Co. ✓

3. Address of Operator
P.O. Box 2160, Hobbs, NM 88241

4. Well Location
Unit Letter G : 1980 Feet From The North Line and 1980 Feet From The East Line

Section 24 Township 20S Range 27E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3350 GR

7. Lease Name or Unit Agreement Name

Mach Norte Com.
Mach Norte Com.

8. Well No.

2

9. Pool name or Wildcat
Burton Flat Morrow

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set CIBP @ 11,200'± cap with 35' cement.
- Shoot and pull 5½" csg. 100' 9630-4530 Top of Penn
- Displace hole with Salt Gel mud.
- Set 100' cement across 5½" csg. stub.
- Set 35 sx plug from 6280-6180 (2nd Bone Springs)
Set 35 sx plug from 4732-4632 (1st Bone Springs)
Set 35 sx plug from 2650-2550 across 9 5/8" casing, shoe @ 2600'.
Set 35 sx plug from 710- 610 across 13 3/8" casing, shoe @ 660'.
Set 10 sx plug at surface.
- Clean location, set dry hole marker.
- Get location ready for inspection by OCD.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE J.T. Janica TITLE VP DATE 2/12/90

TYPE OR PRINT NAME J.T. Janica

TELEPHONE NO. (505) 392-2112

(This space for State Use)

APPROVED BY [Signature] TITLE STATE OIL INSPECTOR DATE 2-27-90

CONDITIONS OF APPROVAL, IF ANY: