

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Texaco E&P, Inc.

3. Address and Telephone No.

P. O. Box 3109 - Midland, TX 79702

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit Letter G, 2110' FNL and 1980' FEL Sec. 34 T-²²~~25~~ R26-E

NM OIL CONS COMM
Drawer DD
Artesia, NM 88210

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.
NM-31202

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

Unit Letter G

8. Well Name and No.

Federal "34" #1

9. API Well No.

30-015-22437

10. Field and Pool, or Exploratory Area

South Carlsbad-Morrow

11. County or Parish, State

Eddy

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Notify BLM of intent to plug and abandon well prior to moving on well.
2. TIH w/tubing to 4883', tag cement plug; circ. casing w/25# per bbl. salt gel mud.
3. Rig up wireline and perf. 7-7/8" casing @ 2120' and squeeze w/85 sacks cement below cement retainer, set at 2000'. WOC & test retainer for leak.
4. Spot 20 sacks cement on CICR @ 2000' - 1900'.
5. Perf. 7-7/8" casing @ 450' & circ. cement to surface behind casing. Cement w/150 sxs cement w/ cement retainer @ 350'.
6. Spot 100 sx cement from 350' to surface.
7. Nipple down BOP & cut off wellhead; cap well & install dry hole marker. Clean location & move off.

REC'D
JUL 03 1995
OIL COMM. DIV.
DISC?

14. I hereby certify that the foregoing is true and correct

Signed

Title Operations Engineer

Date 6/7/95

(This space for Federal or State, office use)

Approved by

Title PETROLEUM ENGINEER

Date

JUN 29 1995

Conditions of approval, if any:

SEE ATTACHED

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side