

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

OIL CONSERVATION DIVISION

DISTRICT I
P. O. Box 1980, Hobbs, NM 88240
DISTRICT II
811 S. First St., Artesia, NM 88210-2834
DISTRICT III
1000 Rio Brazos Rd, Aztec, NM 87410

2040 S. Pacheco
Santa Fe, New Mexico 87505

WELL API NO.
30-015-29687

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒ GAS
WELL ☐ OTHER

2. Name of Operator

Hallwood Petroleum, Inc.

3. Address of Operator

P. O. Box 378111, Denver, CO 80237

7. Lease Name or Unit Agreement Name

Catclaw Draw Unit 23

8. Well No.

3

9. Pool name or Wildcat

Catclaw Draw (Delaware)

4. Well Location

Unit Letter K : 1980 Feet From The South Line and 1980 Feet From The West Line
Section 23 Township 21S Range 25E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RI, GR, etc.)
3330' GL 3337' KB

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Hallwood plans to plug and abandon this well as soon as approval is received from the State of New Mexico. We have perfed, acidized, frac'd, tested and plugged back several times and still well produces mostly water. Please see attached Completion Report (Form C-105) for details.

The attached procedures are planned for this plug and abandonment.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Nonya K. Durham TITLE Production Reporting Supervisor DATE 11/5/97

TYPE OR PRINT NAME Nonya K. Durham TELEPHONE NO. 303-850-6257

(This space for State Use)

APPROVED

BY [Signature] TITLE 10-1-98

CONDITIONS OF APPROVAL IF ANY:

CATCLAW DRAW UNIT #23-3

Section 23-T21S-R25E
Eddy County, New Mexico

Procedures to Plug and Abandon

1. Set a 4.5" cement retainer at 2575' on tubing. Establish a pump-in rate into perfs at 2626-2800'.
2. Mix and pump 50 sxs of cement. After pumping approximately half of the cement below the retainer, unsting and displace the rest of cement on top of the retainer. This will provide about 329' of fill up inside the 4 1/2" casing.
add Spot 100' plug across 7" casing shoe @ 2120' (50' in 50' area), Tag
3. TOH to at least 1600' and circulate hole with plug mud.
4. POOH with tubing and stinger to 310' (which is 50' below the 10 3/4" casing shoe), Tag
5. Mix and pump 25-30 sxs of cement which should fill the 4 1/2" casing to surface.
6. TOOH with tubing.
7. Cut off wellhead and install dry hole marker per State specifications.
8. Remove all equipment and restore location per State specifications (refer to original drilling permit for grass/seed mix).