

|                        |  |
|------------------------|--|
| NO. OF COPIES RECEIVED |  |
| DISTRIBUTION           |  |
| SANTA FE               |  |
| FILE                   |  |
| U.S.G.S.               |  |
| LAND OFFICE            |  |
| OPERATOR               |  |

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1

RECEIVED BY  
OCT -8 1986  
ARTESIA, OFFICE

3a. Indicate Type of Lease  
State ☐ Fee ☒  
3. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN, OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT TO DRILL FORM C-1011 FOR SUCH PROPOSALS.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐  
2. Name of Operator  
Belco Development Corporation  
3. Address of Operator  
P. O. Box 2267, Midland, Texas 79702  
4. Location of Well  
UNIT LETTER H 1980 FEET FROM THE north LINE AND 660 FEET FROM  
THE east LINE, SECTION 8 TOWNSHIP 22S RANGE 27E NMPM.

7. Unit Agreement Name  
8. Farm or Lease Name  
Union Mead  
9. Well No.  
1  
10. Field and Pool, or Wildcat  
Carlsbad, S. (Morrow Strawn)

15. Elevation (Show whether DF, RT, GR, etc.)  
GL 3094' KB 3112'

12. County  
Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐  
PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:  
REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

1. MIRU well service unit; kill well; ND tree; NU BOP.
2. Pull tubing to 11,100'. Spot 25 sack plug from 11,100 to 10,900 feet. WOC. Tag top of plug. Circulated hole w/440 bbls 10 ppg brine-gel mud.
3. Pull tubing to 10,250 feet. Spot 25 sack plug from 10,250 to 10,050 feet. WOC. Tag top of plug.
4. Spot 30 sack plug from 8582 to 8432 feet.
5. Spot 40 sack plug from 1825 to 1925 feet.
6. Spot 55 sack plug from 266 to 366 feet.
7. Place 5 sack plug at surface. Cut off wellhead. Weld on plate and dry-hole marker. Clean up location.

hereby certify that the information above is true and complete to the best of my knowledge and belief.

Betty Gildon Betty Gildon TITLE Regulatory Analyst DATE 10/7/86  
Danell Moser Danell Moser TITLE Geologist DATE 12/3/87