

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN THE MANNER INDICATED*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐
2. NAME OF OPERATOR
Jake L. Hamon ✓
3. ADDRESS OF OPERATOR
908 Vaughn Building, Midland, Texas 79701
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
1650' FNL & 2310' FWL of Section 23, T-23-S, R-24-E, NMPM
14. PERMIT NO.
15. EXPLANATIONS (See instructions on reverse side.)
28' GP - 39.9' K.P.

5. LEASE DESIGNATION AND SERIAL NO.
NM 0295264
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Union Federal
9. WELL NO.
1
10. FIELD AND POOL, OR WILDCAT
Rock Tank(Upper Morrow)
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
NMPM
Sec. 23, T-23-S, R-24-E
12. COUNTY OR PARISH
Eddy
13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTEREST TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

REPAIR AFTER CLOSING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

REPAIR AFTER CLOSING

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

GRAB BORE

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR WELL

GRAB BORE

(Other)

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED WORK (Give location, all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well presently producing 100 McFPD and 27 barrels salt water/day. No longer economical to produce.

1. Set cast iron bridge plug in 4-1/2" casing at 10,000' and dump 20' of cement on bridge plug.
2. Shoot off 4-1/2" casing at approximately 9100'.
3. Set 35 sack plug 140' in 7-7/8" hole at following places:
8850' to 8900'; top of Straw Line
7300' to 7200'; Top of Lower Bone Spring Sand
5350' to 5250'; top of Upper Bone Spring Sand
3800' to 3700'; in Bone Spring Line Section
4. Set 10 sack plug 140' in top of 8-5/8" surface casing set at 2549.07'. Plug from 2600' to 2600'.
5. Set 10 sack plug 140' in top of 8-5/8" surface casing and install permanent marker in top of well.
6. Clean and level location.

RECEIVED
JUN 18 1973
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

Production Superintendent

DATE June 14, 1973

(This space for Federal or State official use)

APPROVED BY

DATE

CONDITIONS OF APPROVAL, IF ANY