

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION  
P O BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-73

|                        |  |
|------------------------|--|
| NO. OF COPIES RECEIVED |  |
| DISTRIBUTION           |  |
| SANTA FE               |  |
| FILE                   |  |
| U.S.O.S.               |  |
| LAND OFFICE            |  |
| OPERATOR               |  |

RECEIVED BY

JAN 12 1984

O. C. D.  
ARTESIA OFFICE

5a. Indicate Type of Lease  
State ☒ Fee ☐

5. State Oil & Gas Lease No.  
L-3358

SUNDRY NOTICES AND REPORTS ON WELLS  
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT STRATUM.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.

1. ☐ OIL WELL ☒ GAS WELL ☐ OTHER

7. Unit Agreement Name

8. Farm or Lease Name

Nash Unit

9. Well No.

7

10. Field and Pool, or Wildcat

Nash Draw Morrow

4. Location of Well  
UNIT LETTER D 685 FEET FROM THE North LINE AND 1295 FEET FROM

THE West LINE, SECTION 18 TOWNSHIP 23S RANGE 30E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)

3012' GR

12. County

Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:

1. Set cmt retainer @ 6912' inside 5 1/2" csg and above 4 1/2" drill pipe.
2. Squeeze Morrow perms (13,624' -- 13,859') and fill volume below retainer with 500 sx "C".
3. Displace hole with +9.0 ppg mud laden fluid.
4. Set 25 sx "C" plug from 3315' to 3215' across 13 3/8" csg shoe @ 3265'
5. Find freepoint on 5 1/2" csg.
6. (a) Cut and pull 5 1/2" csg (if economic length) or \* Set Stub plug + tan  
(b) Bring cmt in 9 5/8" / 5 1/2" csg annulus to surface with 1" pipe.
7. If casing pulled, set 25 sx "C" plug 50' in and out of casing stub.
8. Set 10 sx "C" plug from 100' to surface.
9. Install dry hole marker.

RECEIVED  
DEC 7 - 1983

XC: NMOCD-A (O+2), CEN RCDS, ACCTG, MAT CONT, PROD RCDS(FILE), RES ENG, GAS CONT, MIDLAND, PARTNERS, ROSWELL

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. E. Mathis

TITLE REGULATORY COORDINATOR

DATE 12-7-83

APPROVED BY [Signature]

TITLE OIL AND GAS INSPECTION

DATE FEB 15 1984

CONDITIONS OF APPROVAL, IF ANY: \* As Noted. Above. Plugging

Re-submitted 1-11-84

3  
[Signature]

RECEIVED  
JAN 23 1964  
C. C. L.  
ALBANY, CALIF.