

OIL CONSERVATION DIVISION

State of New Mexico
Energy Minerals and Natural Resources Department

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Box Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-015-23757		5. Indicate Type of Lease STATE ☐ FEE ☒		6. State Oil / Gas Lease No.	
MALAGA HARROUN 6		7. Lease Name or Unit Agreement Name			
1. Type of Well: OIL ☒ GAS ☐ OTHER ☐		2. Name of Operator TEXACO EXPLORATION & PRODUCTION INC.		8. Well No. 1	
3. Address of Operator 205 E. Bender, HOBBS, NM 88240		9. Pool Name or Wildcat MALAGA DELAWARE		4. Well Location Unit Letter F : 1980 Feet From The NORTH Line and 1880 Feet From The WEST Line Section 6 Township 24S Range 29E NMPM EDDY COUNTY	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 2954' GR					

NOTICE OF INTENTION TO:

☒ PERFORM REMEDIAL WORK	☐ TEMPORARILY ABANDON	☐ CHANGE PLANS	☐ OTHER:
☐ PLUG AND ABANDON	☐ COMMENCE DRILLING OPERATION	☐ ALTERING CASING	☐ CASING TEST AND CEMENT JOB
☐ REMEDIAL WORK	☐ PLUG AND ABANDONMENT	☐ OTHER:	

SUBSEQUENT REPORT OF:

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Install and test location rig anchors. Prepare blow pit. Comply to all NMOCDD, BLM, and Texaco regulations.
2. MIRU pulling unit. Conduct safety meeting for all personnel on location. NU relief line. Blow down well and kill with water as necessary. ND wellhead and NU BOP. Test BOP.
3. TIH with 2-7/8" working string to CIBP @ 3360'.
4. Plug # 1 (Spot 35' Cmt on CIBP @ 3360'). Circulate 9-5/8" casing with 10# brine mud. Mix 12 sx Class C cement and spot from top of CIBP @ 3360' to 3325'.
5. Plug # 2 (1-3/8" Csg Shoe @ 2762'). Mix 33 sx Class C cement and spot a balanced plug from 2812' - 2712'. POH above cement. Shut in well overnight. WOC. Tag plug with working string.
6. Plug # 3 (100' to Surface): Mix 33 sx Class C cement and spot a plug from 100' to surface. Shut in well, WOC.
7. ND BOP and cut off well head below surface casing. Install P&A marker to comply with NMOCDD regulations. RD pulling unit, cut off anchors, and restore location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE Engr Asst

DATE 1/7/98

TYPE OR PRINT NAME Monte C. Duncan

Telephone No. 397-0418

ORIGINAL SIGNED BY THE M. GUM

APPROVED BY TITLE

CONDITIONS OF APPROVAL, IF ANY:

DATE JAN 20 1998