

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

c/sf
Op

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87505

RECEIVED

APR 17 1992

O. C. D.

WELL API NO.
30-015-25255

5. Indicate Type of Lease
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.
168130

7. Lease Name or Unit Agreement Name
DELTA FEE "B"

8. Well No.
1

9. Pool name or Wildcat
EAST CARLSBAD (WOLFCAMP)

SUNDRY NOTICES AND REPORTS ON WELLS - SPECIAL OFFICE
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER

2. Name of Operator
Marathon Oil Company

3. Address of Operator
P.O. Box 552 Midland, Tx. 79702

4. Well Location
Unit Letter B : 990 Feet From The NORTH Line and 1980 Feet From The EAST Line

Section 14 Township 22-S Range 27-E NMPM EDDY County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
GL 3082' KB 3110'

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1 MIRU. TIH to RBP @ 9650' - MOVE RBP down to 10268 100ft cement on RBP
2 Set 50' Cmt plug on top of BP. Tag Plug 100 ft Plug 9700 - 9600 Tag
3 Circulate hole w/10#/gal brine w/25#/Bbl Gel
4 Set 100' Cmt plug @ 8950' - 8850'
5 Pull 4 1/2" csg. Believed to parted @ (4026'). Set Cmt plug 50' above and below csg stub. Tag Plug. Set Cmt plug 50' above and below 8 5/8" shoe @ 2600'. Tag plug.
7 Set 50' Cmt plug @ surface. Cut off Csg and install dry hole marker

Plug 5500 - 5400

Plug 1735-1835
Plug 500-400 Tag

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Thomas M. Price TITLE Advanced Eng. Tech. DATE 4-10-92

TYPE OR PRINT NAME Thomas M. Price

TELEPHONE NO. 915-687-8327

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep DATE 4/27/92

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness.

Plugged