

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIP DATE  
(Other instruction  
verse side)

Form approved.  
Budget Bureau No. 1004-111-1  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-0404441

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Barclay "11" Federal

9. WELL NO.

1

10. FIELD AND POOL OR WILDCAT

Undesignated (Morrow)

11. SEC., T., R., M., OR B.L. AND  
SURVEY OR AREA

Sec. 11, T-23-S, R-31-E

12. COUNTY OR PARISH

Eddy

13. STATE  
New Mexico

1. (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

OIL WELL ☐ GAS WELL ☐ OTHER ☒ Dry Hole

2. NAME OF OPERATOR

Union Oil Company of California

3. ADDRESS OF OPERATOR

P. O. Box 671, Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

2180' FNL & 660' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3489.9  
GL 3490', DF 3514', KB 3515'

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETION ☐

ABANDON\* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

(Other) Plug and Abandon

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)\*

CONT'D

- 7 - Set CIBP @ 9150' w/cmt plug to 9115'. Bone Springs perms 9182-9240'.
- 8 - Spot cmt plug @ 6948-6798'.
- 9 - Cut and pull 7-5/8" csg from approx 4300'.
- 10 - Spot 100' cmt plug across where csg is cut (50' in & 50' out).
- 11 - Spot cmt plug from 3300-1100' inside 10-3/4" csg across salt.
- 12 - Spot cmt plug from 700-800'.
- 13 - Spot 50' cmt plug at surface.
- 14 - Cut off well hd & install dry hole marker.
- 15 - Remove all equipment & clean location.

FORMATION TOPS

Rustler	-	1150'	Strawn	-	13200'
Lamar	-	4490'	Atoka	-	13555'
Bone Spring	-	8330'	Morrow	-	14100'
Wolfcamp	-	11642'	L. Morrow	-	15070'

18. I hereby certify that the foregoing is true and correct

SIGNATURE  J. R. Hughes

TITLE Dist. Drlg. Supt.

DATE 4-9-86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side