

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPL. (Other instructions on reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Hanson Operating Company, Inc.

3. ADDRESS OF OPERATOR

P. O. Box 1515, Roswell, New Mexico 88202-1515

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface

Sec. 25, T. 26S, R. 31E, Unit 0, 330' FSL & 2310' FEL

14. PERMIT NO.

30-015-05874

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3145' GR

5. LEASE DESIGNATION AND SERIAL NO.

LC-068282-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

N/A

7. UNIT AGREEMENT NAME

N/A

8. FARM OR LEASE NAME

Hanson Federal Batt. #2

9. WELL NO.

#8

10. FIELD AND POOL, OR WILDCAT

North Mason (Delaware)

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 25, T. 26S, R. 31E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANT

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Received verbal approval from Adam Salameh on 02-13-92 to plug and abandon on 02-14-92 in the following manner:

- 1) Tag CIBP set on 02-10-92 w/wireline.
- 2) Set A CIBP @4100'±.
- 3) Run in hole w/tbg and circ well bore w/9# mud ladden fluid.
- 4) Set a 50' 15 sx Class C cem plug on top of CIBP @ 4100'.
- 5) Set a 140' 15 sx Class C cem plug from 3988' to 3848' and tag plug.
- 6) Perf @ 934', set a 100' 25 sx Class C cem plug from 934' to 834' and tag plug.
- 7) Perf at 50' and circ cem inside & outside.
- 8) Install dry hole marker and clean location.

All cem plugs will be Class "C" w/2% CaCl mixed @ 14.8#/gal.

Notified Jim Amos w/BLM on 02-13-92

18. I hereby certify that the foregoing is true and correct

SIGNED

Lisa L. Jennings

TITLE Production Analyst

DATE 02-13-92

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

2/27/92

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side