

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRI-
(Other instruction.
verse side)

ATE*

Form approved.
Budget Bureau No. 42-R1424.

6. LEASE DESIGNATION AND SERIAL NO.

NM-0522

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☒	2. NAME OF OPERATOR PAN AMERICAN PETROLEUM CORPORATION	3. ADDRESS OF OPERATOR BOX 68, HOBBS, N. M. 88240	4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FSL x 660' FEL, Sec 28 (Unit P, SE 1/4 SE 1/4)	5. UNIT AGREEMENT NAME POKER LAKE UNIT Federal	6. WELL NO. 36	7. FIELD AND POOL, OR WILDCAT WILDCAT MORROW GAS	8. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 28-24-31 NMPM	9. COUNTY OR PARISH EDDY	10. STATE N.M.
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3502' RDB								

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Efforts to increase productivity of well failed. No further workover possibilities exist. Work done and proposed disposition of well as follows:

Perforated additional Morrow plungers 14740-55, 14910-25, 14940-44 w/25SPF. evaluated. Unable to swab well off. 51' for press buildup. Bled from 1600' to 0' in 20 min.

In view of the above, we propose to Plug and Abandon as follows: ① Shoot and pull 7" log from true point - Est top cmt 11800'. ② Shoot + pull 9 5/8" log from true point - TCMT 7775'. ③ Spot 100 SF Cement plug 14540-15060; 50 SX in + out of 9 5/8" log. Plug 20 SF from 6100-6000; Spot 10 SX @ surface + erect P.A. marker. Make final cleanup and restore ground to contour. (Purchant to tele conv. Jones to M. Knapp 1-8-68)

20" CSA 875 - Cmt Line

1378 CSA 4513 - " "

9 5/8" CSA 12551 - TCMT 7775

7" CSA 12320 to 16526 (Est TCMT 11800' on tie back string)

TD - 16,600'

PBD - 15,767

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

AREA SUPERINTENDENT

DATE

1-9-68

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side