

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER <u>Dry Hole</u>		5. LEASE DESIGNATION AND SERIAL NO. <u>N. M. 11044</u>	
2. NAME OF OPERATOR <u>Curtis Hankamer</u>		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR <u>9039 Katy Freeway Suite 430 Houston, Texas 77024</u>		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface <u>660' FNL & 660' FEL Sec. 5, T-26-S, R-30-E</u> <u>Eddy County, New Mexico</u>		8. FARM OR LEASE NAME <u>Hankamer Federal</u>	
14. PERMIT NO. <u>N/A</u>		9. WELL NO. <u>1</u>	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) <u>3160 GR</u>		10. FIELD AND POOL, OR WILDCAT <u>Wildcat</u>	
16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data		11. SEC., T., R., M., OR BLM. AND SURVEY OR AREA <u>5-26-30</u>	
12. COUNTY OR PARISH <u>Eddy</u>		13. STATE <u>New Mexico</u>	

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐

SUBSEQUENT REPORT OF:

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Drilled 12 1/4" hole to 425' - Ran and cemented 8 5/8" OD casing at 421' - Drilled 7 7/8" hole to TD @ 5368' - open hole cement plugs as follows: 5100' to 5000' w/35 sks Class "H" cement and 4050' to 3950' w/35 sks Class "H" cement. Ran 4 1/2" OD casing set at 3846' cemented w/250 sks cement. Tested perforations 3668' to 3680' and 3683' to 3691' (Ramsey Zone of the Delaware Section) found to be non-hydrocharbo-productive.

Proposed Plugging Procedure:

1. Inside casing 25 sack cement plug from 3695' to 3335'±.
2. Shoot off casing above cement at approximately 3020' and pull same out of hole.
3. Run tubing into hole and spot cement plugs as follows:
25 sks from 3030' to 2970'±
50 sks from 1150' to 1050'±
125 sks from 450' to 250'±
20 sks from 30' to ground level
4. Weld cap on 8 5/8" casing and install 4 1/2" pipe marker in top of 8 5/8" casing protruding 5' above ground level.

Captioned well was P & A on September 17 and 18, 1977, while completion rig was on location. Mr. James Knauf, District Engineer, U. S. Geological Survey Office, Artesia, New Mexico recommended and approved plugging procedure.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature]TITLE AgentDATE 1/25/78

(This space for Federal or State office use)

APPROVED BY [Signature]

CONDITIONS OF APPROVAL, IF ANY:

TITLE ACTING DISTRICT ENGINEERDATE MAR 1 - 1978

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.