

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☐ Oil Well ☐ Gas Well ☒ Other **GAS STORAGE WELL**

2. Name of Operator
EL PASO NATURAL GAS COMPANY, J. W. MULLOY, AGENT

3. Address and Telephone No.
1110 N. BIG SPRING, MIDLAND, TX 79701 - 915/687-0323

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
1045 FSL & 512' FEL, SEC 33, T-25-S, R-24-E

5. Lease Designation and Serial No.
NM 22207

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation
**WASHINGTON RANCH
STORAGE PROJECT**

8. Well Name and No.
W. I. WELL #12

9. API Well No.

10. Field and Pool, or Exploratory Area
WASHINGTON RANCH

11. County or Parish, State
EDDY CO., N.M.

CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
- ☐ Subsequent Report
- ☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
- ☐ Recompletion
- ☐ Plugging Back
- ☐ Casing Repair
- ☐ Altering Casing
- ☐ Other
- ☐ Change of Plans
- ☐ New Construction
- ☐ Non-Routine Fracturing
- ☐ Water Shut-Off
- ☐ Conversion to Injection
- ☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 1) Notify BLM 24 hrs prior to commence of work.
- 2) Rig up & install BOPs.
- 3) POH w/2-7/8" tubing & Baker "D" packer.
- 4) Set CIBP @ 6840'.
- 5) RIH w/2-7/8" tbg. Load hole w/9 #/gal. mud.
- 6) Spot plug on top CIBP @ 6840' back to 6790'.
- 7) POH w/2-7/8" tbg.
- 8) Cut 7" casing @ 4140' & recover.
- 9) RIH w/2-7/8" tbg. & spot cement plug from 4140' to 4090'.
- 10) WOC 6 hrs & tag plug @ 4140' 4090'.
- 11) Spot cement plug from 3800' back to 3700'.
- 12) Spot cement plug from 850' back to 750'.
- 13) WOC 6 hrs and tag plug @ 750'.
- 14) Set 50' cement plug @ surface.
- 15) Set surface marker.

14. I hereby certify that the foregoing is true and correct

Signed J. W. Mulloy (J.W. Mulloy) Title AGENT

Date 9/28/93

(This space for Federal or State office use)

Approved by _____
Conditions of approval, if any:

Title _____

Date 10/15/93

SEE ATTACHED