

45F

RECEIVED BY

BUREAU OF LAND MANAGEMENT

Artesia, NM 88210

SUNDRY NOTICES AND REPORTS ON WELLS

JUN 28 1985

Use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. ☒ OIL WELL ☒ C. D. WELL ☐ OTHER  
2. ARTESIA OFFICE

3. J.C. Williamson

4. P.O. Box 16 Midland, Texas 79702

LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

1980' FSL & 1980' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, ST OR, etc.)

2936.9 GR

6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
NM 35607

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

UCBHW Federal

9. WELL NO.

4

10. FIELD AND POOL, OR WILDCAT

Brushy Draw Delaware

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 25

T-26-S, R-29-E

12. COUNTY OR PARISH 13. STATE

Eddy

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐  
FRACTURE TREAT ☒ MULTIPLE COMPLETE ☐  
SHOOT OR ACIDIZE ☒ ABANDON\* ☐  
REPAIR WELL ☐ CHANGE PLANT ☐

(Other) Acidize & fracture treat

WATER SHUT-OFF ☐ REPAIRING WELL ☐  
FRACTURE TREATMENT ☐ ALTERING CASING ☐  
SHOOTING OR ACIDIZING ☐ ABANDONMENT\* ☐

(Other)  
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Request for approval to Acidize & fracture treat the UCBHW #4 as follows:

- 1) Rig up recompletion unit, pull rods and tubing, GIH w/tubing and packer, set packer @ 5300', test lower pipe to 4000#.
- 2) Move packer up 4700', set and test annulus to 2000#, if holds proceed, if not squeeze and drill out perfs from 4494-4546'.
- 3) Reperforate well from 5118-5150' w/12 holes.
- 4) Reacidize Williamson sand w/3000 gals. 7 1/2% acid.
- 5) Swab back acid, test well.
- 6) Fracture treat w/60,000 gals. gelled KCl water @ 40 BPM, 2000#, w/90,000# 20-40 sand, tailing in w/10,000# 10-20 sand, shut well in overnight to let gel break up.
- 7) Flow back and recover load.
- 8) Flow back load and swab back load.
- 9) Return well to production

18. I hereby certify that the foregoing is true and correct

SIGNED

Kyle D. Schmidt

TITLE

Agent

DATE

5-31-85

(This space for Federal or State office use)

APPROVED BY

C. J. ...

TITLE

DATE

6-27-85

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side