

OCD

Form 3160-5
(June 1990)

RECEIVED

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-
Expires: March 31, 199

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well ☒ Oil Well ☐ Gas Well ☐ Other	5. Lease Designation and Serial NM20369
2. Name of Operator J. C. Williamson	6. If Indian, Allottee or Tribe Sun Ex Unit
3. Address and Telephone No. P.O. Box 16 Midland, TX 79702 (915) 682-1797	7. If Unit or CA, Agreement De Sun Ex Unit
4. Location of Well (Postage, Sec., T., R., M., or Survey Description) 330' FSL 8467' FEL Section 15 T-26-S R-30-E Unit P	8. Well Name and No Sun Ex Federal Unit #3
	9. API Well No. 30-015-24779
	10. Field and Pool, or Explorer Ross Draw Delay
	11. County or Parish, State Eddy County, N

12 CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
☒ Notice of Intent P&A	☒ Abandonment
☐ Subsequent Report	☐ Recompletion
☐ Final Abandonment Notice	☐ Plugging Back
	☐ Casing Repair
	☐ Altering Casing
	☐ Other
	☐ Change of Plans
	☐ New Construction
	☐ Non-Routine Fracturing
	☐ Water Shut-Off
	☐ Conversion to Injection
	☐ Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directed to give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plugback depth at 5880'.

Rig up unit.

Spot 50 sax on formation over perfs @ 5735-5764' - 24 holes. [TAG]

★ Find free point on 4-1/2" casing.

Cut casing and spot 50 sax plug on stub.

Set 50 sax in & out @ 3750', bottom of 7".

Set 25 sax in & out @ 401', bottom of surface, and OIL CON. DIV.

25 sax in surface.

Set marker.

Clean location as per BLM specifications.

* free pt. of 4 1/2" will dictate sequence of P&A... if free pt. is well below 7" csq. shoe, two separate plugs may need to be set, one @ the stub, the other @ the shoe, and each one tagged. If free pt. is near 7" shoe, one large plug may be used to cover both the shoe & the stub, w/only one tag required. If 4 1/2" csq. is free well above 7" shoe, one plug may be set @ the shoe and another @ the stub above and tagging may be optional. SJS

14. I hereby certify that the foregoing is true and correct

Signed Mary Jane Williamson for Title Georgi W. Kingree Engineer Date 12-13-95

(This space for Federal or State office use)

Approved by Org. Signed by Shannon J. Shaw
Conditions of approval, if any:

Title PETROLEUM ENGINEERDate 12/14/95