

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-015-24836
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	LG-1171
7. Lease Name or Unit Agreement Name	Flower AGA State
8. Well No.	1
9. Pool name or Wildcat	Red Bluff Brushy Canyon

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator YATES PETROLEUM CORPORATION	
3. Address of Operator 105 South 4th St., Artesia, NM 88210	
4. Well Location Unit Letter <u>I</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>660</u> Feet From The <u>East</u> Line Section <u>3</u> Township <u>26S</u> Range <u>28E</u> NMPM <u>Eddy</u> County <u></u>	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 2937' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. NOTIFY OCD - ARTESIA (505-748-1283) 24 HOURS PRIOR TO COMMENCING OPERATIONS.
Propose to plug and abandon well as follows:

1. Set CIBP at 5989' and cap with 35' of cement.
2. Load hole with plugging mud.
3. Spot a 25 sack cement plug at 4680' (Brushy Canyon top at 4630').
4. Spot a 25 sack cement plug at 3460' (Cherry Canyon top at 3410').
5. Spot a 35 sack cement plug at 2850' (8-5/8" shoe at 2795' & Bell Canyon top at 2520'). WOC. Tag plug.
6. Stretch, cut and pull 4-1/2" casing (cement top at 2220').
7. Spot a 25 sack cement plug (50' in and out of 4-1/2" stub). WOC. Tag plug.
8. Stretch, cut and pull 8-5/8" casing (cement top at 1700').
9. Spot a 35 sack cement plug (50' in and out of 8-5/8" stub).
10. Spot a 35 sack cement plug at 469' (across 13-3/8" shoe at 419'). WOC. Tag plug.
11. Set a 100' cement plug at surface. Install regulation abandonment marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE 3-8-95
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

ORIGINAL SIGNED BY TIM W. GUM
DISTRICT II SUPERVISOR

APPROVED BY PIA 7-7-95
CONDITIONS OF APPROVAL, IF ANY:

DATE MAR 30 1995