

November 1983
Formerly G-331

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions
verse side)

Budget Bureau No. 1004-1

Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL

NM 55947

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

JUL 24 10 44 AM '91

AUG 02 1991

O. C. D.

ARTESIA, OFFICE

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Cotton Draw Fed Com

WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Wildcat (Morrow)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 23, T24S, R31E

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Fortson Oil Company

3. ADDRESS OF OPERATOR

301 Sommerce Street, Suite 3301, Fort Worth, Texas 76102

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' FNL & 660' FWL, SW/4 NW/4, Unit Letter E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3554' GR

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Proposed plug setting depths for plugging and pulling the 9 5/8" casing.

- 1.) Set a 7" CIBP at 14,400', spot a 10 sack cement plug (50').
- 2.) Spot a 55 sack plug (200') from 11,622' - 11,822'.
- 3.) Cut 9 5/8" casing at approximately 9000', pull and lay down casing. Spot an 105 sack plug (200') from 9100' - 8900'. Wait on cement and tag plug.
- 4.) Spot a 65 sack plug (100') from 6050' - 5950'.
- 5.) Spot a 125 sack plug (200') from 4550' - 4350', wait on cement and tag plug.
- 6.) Spot a 65 sack plug (100') from 756' - 656'.
- 7.) Spot a 35 sack plug (50') at surface.
- 8.) Install dry-hole marker.
- 9.) Clean and level location.
- 10.) Backfill, level and re-seed pits as soon as possible.
- 11.) Rip road and location; reseed as per stipulations.

18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE

Agent

DATE

7/23/91

(This space for Federal or State office use)

APPROVED BY

[Signature]

TITLE

DATE

7/31/91

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.