

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

Contract #103

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Jicarilla Apache

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Jicarilla "H"

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Tapacito Pictured Cliffs

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREASec. 17, T-26N, R-4W,
N.M.P.M.

12. COUNTY OR PARISH 13. STATE

Rio Arriba

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL ☐ GAS ☒
WELL WELL OTHER

2. NAME OF OPERATOR

Southern Union Production Company

3. ADDRESS OF OPERATOR

P.O. Box 808, Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface1650 feet from the North line and 1650 feet from
the East line.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6771 D.F.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☒MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*Due to the uneconomic status of the Jicarilla "H" No. 2 it is therefore intended to
plug and abandon the subject well as follows:

1. Rig up and pull 2-3/8" E.U.E. tubing.
2. Put Class "A" cement plug from 3350 feet to total depth (3489 ft.).
3. Cut 4-1/2" casing off and put 100 feet plug over cut off, 50 ft. in and 50 ft. out.
(If cut off is below OJO ALAMO cover base of Ojo Alamo w/100 ft. cmt. plug.
4. Put cement plug @ 225 ft. to 175 ft.
5. Put 10 aks. plug @ surface w/dry hole marker.
6. Restore locations.



18. I hereby certify that the foregoing is true and correct

SIGNED

Jim Bonaventura
Jim Bonaventura

TITLE

Production Superintendent

DATE

Sept. 30, 1976

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side