

Form 9-331
(May 1963)

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
1-22-IND-2772

6. IF INDIAN, ALLOTTEE OR TRIBE NAME
UTE MOUNTAIN TRIBE OF INDIANS

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
BARKER DOME

9. WELL NO.
3

10. FIELD AND POOL, OR WILDCAT
BARKER CREEK DAKOTA

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 21, T-32N, R-14W, N.M.P.M.

12. COUNTY OR PARISH
SAN JUAN

13. STATE
NEW MEXICO

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR
SOUTHERN UNION PRODUCTION COMPANY

3. ADDRESS OF OPERATOR
P. O. Box 808

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface 1880 FT. FROM THE SOUTH LINE AND 1080 FEET FROM THE WEST LINE.

14. PERMIT NO.
15. ELEVATIONS (Show whether DF, FT, GR, etc.)
6581 FT. D.F.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other)

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other)

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

WE PROPOSE TO PLUG AND ABANDON THE WELL AS FOLLOWS: THE WELL IS LOCATED LOW ON THE STRUCTURE AND IS PRESENTLY NON-PRODUCTIVE.

1. SET CEMENT PLUG OVER DAKOTA FORMATION FROM TOTAL DEPTH OF 2340 FT. TO 2139 FT., USING 35 SACKS OF CEMENT. TOP OF CEMENT WILL BE 100 FT. UP IN BOTTOM OF 5 1/2" CASING.
2. FILL 5 1/2" CASING WITH 9.0#/GAL. MUD FROM 2139 FT. TO 275 FT.
3. PERFORATE 2 HOLES IN 5 1/2" CASING AT 275 FT. CEMENT THRU HOLES WITH 120 SACKS OF CEMENT TO SET PLUG IN ANNULUS BEHIND 5 1/2" CASING FROM 275 FT. TO 100 FT. DISPLACE CEMENT IN 5 1/2" CASING DOWN TO 225 FT. LEAVING 50 FT. OF CEMENT ABOVE PERFORATIONS INSIDE CASING.
4. SET 5 SACK CEMENT PLUG IN TOP OF 5 1/2" CASING FROM 40 FT. TO SURFACE.
5. ALL OF 5 1/2" CASING WILL BE LEFT IN THE WELL.
6. ERECT DRY HOLE MARKER, CLEAN LOCATION AND ABANDON WELL.

RECEIVED

MAR 13 1970

U. S. GEOLOGICAL SURVEY

DURANGO, COLO.

DATE MARCH 12, 1970

18. I hereby certify that the foregoing is true and correct

Original signed by

SIGNED GILBERT D. NOLAND, JR. TITLE DRILLING SUPERINTENDENT

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE
DATE