

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
OG 78-1	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Trans Delta Oil & Gas Company, Inc. (for Shar Alan Oil Company)		8. Farm or Lease Name Lillian State
3. Address of Operator 1008 Ridglea Bank Building, 6300 Ridglea Place, Fort Worth, Texas 76116		9. Well No. 2-X
4. Location of Well UNIT LETTER <u>P</u> <u>1223</u> FEET FROM THE <u>East</u> LINE AND <u>866</u> FEET FROM THE <u>South</u> LINE, SECTION <u>2</u> TOWNSHIP <u>24N</u> RANGE <u>1W</u> NMPM.		10. Field and Pool, or Wildcat So. Blanco PC
15. Elevation (Show whether DF, RT, GR, etc.) GR 7176		12. County Rio Arriba

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We plan to plug and abandon on or about September 25, 1978.

1. Set a plug from TD (2757') to 2450' using 28 sacks of cement.
2. We will not salvage casing.
3. Set plugs as follows:
 - a. Perforate at 900' and set a 100' plug inside and outside 4½" casing using 25 sacks and squeezing 14 sacks through the perforations.
 - b. Shut down 6 hours minimum with accelerated cement and 12 hours with neat cement. Tag cement plug.
 - c. Perforate at 200' and set a 100' plug inside and outside of 4½" casing using 25 sacks, squeezing 14 sacks through the perforations.
 - d. Set marker and stabilize 4½" casing inside the surface casing.
4. Remove all junk from location.
5. Clean and restore location to pre-existing conditions.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>James B. Sparks</u>	TITLE <u>Land Department</u>	DATE <u>9/12/78</u>
APPROVED BY <u>AR Kendrick</u>	TITLE <u>Assistant Secretary</u>	DATE <u>11/1978</u>
CONDITIONS OF APPROVAL, IF ANY:		