Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

/	P	ORM	I AP	PRC)VE	D
Bu	dea	Bun	teu l	No.	1004	-0135
	Expi	res:	Ma	rch i	M. N	193

			** * * * * * * * * * * * * * * * * * * *
£:		farch 3	1005
CAPI	rea; re		נדכו,ו

6. If Indian, Allottee or Tribe Name

¬ NM 013492

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT-" for such proposals

SUBMI	7. If Unit or CA, Agreement Designation	
1. Type of Well	West Bisti Unit	
X Well Gas Other	8. Well Name and No.	
2. Name of Operator	West Bisti Unit 102	
Dugan Production Corp.	9. API Well No.	
3. Address and Telephone No.	30-045-05841	
P.O. Box 420, Farmington,	10. Field and Pool, or Exploratory Area	
4. Location of Well (Footage, Sec., T., R., M., or Survey E	Bisti Lower Gallup	
1980' FSL - 1165' FWL Sec. 18, T26N, R13W, NMPM	11. County or Parish, State San Juan, NM	
2. CHECK APPROPRIATE BOX	s) TO INDICATE NATURE OF NOTICE, REPOR	T, OR OTHER DATA
TYPE OF SUBMISSION		
Subsequent Report AUG 0 8	Recompletion Plugging Back 1991. Casing Repair Altering Casing Other Other	Change of Plans New Construction Non-Routine Fracturing Water Shut-Off Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well
DIST	r. 3	Completion or Recompletion Report and Los form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plug to abandon using Class "B" cement plugs as follows:

- 1. Tag cement plug already present at 5045'. If plug is found on depth, Gallup (5185') is covered.
- 2. Load hole with 9 lb./gal. mud.
- 3. Perforate 50' below Mesa Verde top (2630') @ 2680', and spot 100' cement plug inside and outside casing with 100% excess.
- 4. Perforate 50' below Chacra top (1920') @ 1970', and spot 100' cement plug inside and outside casing with 100% excess.
- 5. Perforate 50' below Pictured Cliffs top (1705') @ 1755', and spot cement plug to 50' above Fruitland top (1582') with 100%
- 6. Perforate 50' below surface casing (208') @ 258', and pump cement down 53 casing until cement returns to surface a braden head. Leave inside and outside of casing full of cement.
- 7. Cut off well head and install dry hole marker.

· · · · · · · · · · · · · · · · · · ·		
14. I hereby certify the forefoirs is tree and correct Signed John Clyanal	Title Operations Manager	Date 7/12/9/
(This space for Federal or State office use) Approved by Conditions of approval, if any:	CONDITIONS OF APPROVAL	15 John Skiller

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States say false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

UNITED STATES DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT FARMINGTON RESOURCE AREA 1235 LA PLATA HIGHWAY FARMINGTON, NEW MEXICO 87401___

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

The second secon

- 1. Plugging operations authorized are subject to the attached "General" Requirements for Permanent Abandonment of Wells on Federal Leases.
 - with the Farmington Office is to be notified ... at least 24 hours before the plugging operations commence (505) 326-6201.

 3. Blowout prevention equipment is required.

 - 4. The following modifications to your plugging program are to be made (when

397 and Coment to surface (Bise of Ojo Hand 347 cal Top of 0,0 Atom (a) 250)

Office Hours: 7:45 a.m. to 4:30 p.m.

GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES FARMINGTON RESOURCE AREA

and the factor of the last of the factor of

- 1. Secure prior approval either on a Sundry Notice (Form 3160-5) or verbally from the Fluids Drilling & Production Section at this office before changing the approved plugging program.
- 2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs. The Operator is responsible for providing all measuring devices needed to assure proper measurement of materials being used.
- 3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations. Unattended pits are to be fenced.
- 4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 100 feet in length with 50% excess inside casing or 100% excess when plug is set in open hole or squeezed into perforations. 15.6#/gal slurry weight is to be used when using class B neat cement or when CaCl2 is used.

 Use the recommended slurry weight of other type cements when they are used (Class C, Pozzolan etc.).
 - 25. Any cement plugs placed when well is not full of fluid, or when well may be taking fluid, (i.e. across perfs unless bridge plug or retainer is used, across bad csg., or fresh water formations) will be tagged (touched) after cement has set to verify proper location.
- 5a. Testing The first plug below the surface plug shall generally be tested by either tagging the plug with the working pipe string, or pressuring to a minimum pump (surface) pressure of 1000 psig, with no more than a 10 percent drop during a 15-minute period (cased hole only). If the integrity of any other plug is questioned, it must be tested in the same manner. Also, any cement plug which is the only isolating medium for a fresh water interval or a zone containing a valuable mineral deposit should be tested by tagging with the drill string.
 - 6. Mud must be placed between plugs. Plugging mud is to be made up with a minimum of 15 lbs/bbl of sodium bentonite, and a nonfermenting polymer.

 Minimum consistency of plugging mud must be 9 lbs/gal and with a minimum viscosity of 50 sec/qt. Fresh water is to be utilized for mixing mud.
 - 7. Following the placement of a cement plug, the withdrawl rate for at least the length of the cement plug shall not exceed 30 ft/min, in order to minimize the contamination of the plug.

- 8. Within 30 days after plugging work is completed, file a Sundry Notice (Subsequent Report of Abandonment, Form 3160-5), in quintuplicate with Area Manager, Bureau of Land Management, 1235 La Plata Highway, Farmington, NM 87401. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was some plugged.
- 9. All permanently abandoned wells are to be marked with a regulation marker (4" pipe extending 4' above the ground line) containing the information as are specified in 43 CFR 3162.6(d). Unless otherwise approved.
- 10. After plugging work is completed the surface is to be rehabilitated in accord with instructions from the Fluids Surface Management Section of the Farmington Resource Area Office.

All above are minimum requirements. The period of liability under the bond of record will not be terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.

Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to:43 CFR 3163.1.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.

The first control of the control of

andri variante de la composició de la co

్ ముందుకుండి కారు మండుకుండి కారు మండుకుండి. మండుకుండి కార్యానికి అన్ని కార్యానికి కార్యానికి అన్ని క్రిక్స్తి మండుకుండి కార్యానికి కార్యానికి కార్యాన్ కార్యాన్కి కార్యాన్ని కార్యాన్ని కార్యాన్ని కార్యాన్ని కార్యాన్ని క్రి కార్మం మెందుకుండి కార్యాన్ని కార్యాన్ని కార్యాన్ కార్యాన్ని కార్యాన్ని కార్యాన్ని కార్యాన్ని కార్యాన్ని క్రిక్