

3-00C
1-F

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
<input checked="" type="checkbox"/> State <input type="checkbox"/> Federal <input type="checkbox"/> Foreign
5. State Oil & Gas Lease No.
SF-078089

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
Beta Development Co.	Scott Federal
3. Address of Operator	9. Well No.
234 Petroleum Club Plaza, Farmington, New Mexico	12
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER D, 1190 FEET FROM THE North LINE AND 990 FEET FROM THE West LINE, SECTION 36 TOWNSHIP 27 N RANGE 11 W NMPM.	Basin Dakota
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
6515' G.L.	San Juan

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Repair casing leaks w/packer and Kem-Pac chemicals, as follows:

Rig up workover rig, circulate out mud, sand and shale to T.D. Circulate until hole is clean. POH. Run Baker Model "D" production packer on wire line. Set packer just below Greenhorn section w/bump out plug to keep any water or Kem-Pac material from getting below packer. GIH w/t/bg., Model "D" locator and tail pipe. Spot Kem-Pac above Model "D", set tail pipe down on bump out plug, run tail pipe through Model "D" and land locator seals in packer. Flange up well head, swab well in and re-acidize if necessary.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by:
D. E. BAXTER

SIGNED _____ TITLE Superintendent DATE February 24, 1967

APPROVED BY Emory C. Clure TITLE SUPERVISOR DIST. #3 DATE FEB 27 1967

CONDITIONS OF APPROVAL, IF ANY: