4-11563 Form 9-331 (May 1963)

1-F

UNITED STATES DEPARTMENT OF THE INTERIOR (Other instructions verse side) GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE.

Form approved. Budget Bureau No. 42-R1424 5. LEASE DESIGNATION AND SERIAL NO.

. IF INDIAN, ALLOTTEE OR TRIBE NAME

SF-0	78	394
------	----	-----

(1	Do not	SUN use this	VDR's form	Y NOTICE for proposals "APPLICATIO	S AND REPORTS ON WELLS to drill or to deepen or plug back to a different reservoir. N FOR PERMIT—" for such proposals.)	
.T.	۲٦	GAS	K	OTHER		7

. UNIT AGREEMENT NAME

NAME OF OPERATOR Beta Development Co. 3. ADDRESS OF OPERATOR

8. FARM OR LEASE NAME Hancock Federal

234 Petroleum Club Plaza, Famington, New Mexico

9. WELL NO.

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.)
At surface

10. FIELD AND POOL, OR WILDCAT

790/N 990/E

Basin Dakota

24-27%-1177

抵認

14. PERMIT NO.

15. BLEVATIONS (Show whether DF, RT, GR, etc.) 6114° GR

12. COUNTY OF PARISH | 18. STATE San Juan New Rexico

(Other)

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

ROTI	NOTICE OF INTENTION TO:				
TEST WATER SHUT-OFF		PULL OR ALTER CASING			
FRACTURE TREAT		MULTIPLE COMPLETE			
SHOOT OR ACIDIZE		ABANDON*			
REPAIR WELL	X	CHANGE PLANS			

SUBSEQUENT REPORT OF: WATER SHUT-OFF REPAIRING WELL FRACTURE TREATMENT ALTERING (ASING SHOOTING OR ACIDIZING ABANDON MENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Repair casing leaks w/packer and Kem-Pac chemicals, as follows:

Rig up workever rig, circulate out said, sand and shale to T.D. Circulate until hole is clean. PCH. Run Baker Model "D" production packer on wire I line. Set packer just below Greenhorn section w/bump out plug to keep any water or Kem-Pac material from getting below packer. Gill m/tbg.. Model "D" locator and tail pipe. Spot Kem-Pac above Model "D", set tail pipe down on bump out plug, run tail pipe through Kedel "D" and land locator seals in packer. Flange up wellhead, swab well in and re-acidize if necessary.

MAR 1 3 1967 OIL CON. COM DIST. 3

MAR 1.0 1987

U. S. GEOLOGICAL SURVEY. EARMINGTON, N. M.

18. I hereby certify the right of the same correct signed D. E. BAXTER	TITLE	Superintendent	DATE Larch 9, 1967
(This space for Federal or State office use)			
APPROVED BYCONDITIONS OF APPROVAL, IF ANY:	TITLE		 DATE