

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.

SUBMIT IN TRIPLICATE

FORM APPROVED
Budget Bureau No. 1004 0135
Expires: March 31, 1993

Lease Designation and Serial No
NMSF-078478

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

UNIT G

8. Well Name and No.

FEDERAL E2

9. API Well No.

10. Field and Pool, or Exploratory Area

BLANCO MESAVERDE

11. County or Parish, State

SAN JUAN, NEW MEXICO

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

TOP OF NACIMIENTO 531'
TOP OF OJO ALAMO 1368'
TOP OF KIRTLAND 1510'
TOP OF FRUITLAND 1998'
TOP OF PICTURED CLIFFS 2211'
TOP OF LEWIS 2320'
TOP OF CHACRA 3120'
TOP OF CLIFF HOUSE 3873'
TOP OF MENEFEE 3890'
TOP OF POINT LOOKOUT 4476'
TOP OF MANCOS 4680'

PLEASE SEE ATTACHED
FOR PROCEDURES

14. I hereby certify that the foregoing is true and correct.

Signed [Signature] Title PETROLEUM ENGINEER

Date 2/16/96

(This space for Federal or State office use)

Approved by
Conditions of approval, if any:

Title

Date

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

BLEDSON PETRO CORPORATION
PLUGGING PROCEDURES
FEDERAL E 2

- 1) Set CIBP @ 3823' and spot 50' of cement on top of plug
- 2) Perf @ 3170', place cement plug from 3170' to 3070' inside and outside the casing with 100% excess cement in the annulus and an additional 50 linear feet inside the casing.
- 3) Perf @ 2048', place cement plug from 2048' to 1948' inside and outside with 100% excess in the annulus and an additional 50 linear feet inside the casing.
- 4) Perf @ 1560', place cement plug from 1560' to 1318' inside and outside casing with 100% excess in the annulus with and 50 linear feet inside the casing.
- 5) Perf @ 581' and circulate cement to surface.