

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1724

5. LEASE DESIGNATION AND SERIAL NO.

078108&A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

New Mexico Federal "K"

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Undesignated

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 34, T-30-N, R-15-W

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR
Sunray DX Oil Company

3. ADDRESS OF OPERATOR
P. O. Box 1416, Roswell, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980 FSL & 1980 FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5337 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
(Other) <input type="checkbox"/>	Plug & Abandon <input checked="" type="checkbox"/>

SUBSEQUENT REPORT OF:

WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Present PBD 4513'.
2. Top of cmt behind 4 1/2" prod. csg 3850'. 8 5/8" surf csg @ 167' w/125 sxs cmt circulated to surface. Perf @ 4476 notch. Prod. csg set @ 4523' w/175 sx cmt.
3. Load hole with mud.
4. Cut off csg @ approx 3750'. Pull prod. csg. Keep hole loaded w/mud.
5. Place 10 sx cmt plug (4433'-4513') to cover perfs.
6. Place 10 sx cmt plug in & out of 4 1/2" stub (3720-80').
7. Set 17 sx cmt plug in & out of 8 5/8" surf csg (137'-197').
8. Set 10 sx cmt plug @ surface.
9. Install dryhole marker.
10. Remove surface equipment & clean up location.

RECEIVED
NOV 17 1966
U. S. GEOLOGICAL SURVEY
FARMINGTON, N. M.

18. I hereby certify that the foregoing is true and correct

SIGNED B.F. Brawley B.F. Brawley TITLE District Engineer DATE 11-14-66

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

NOV 17 1966
John K. Alford
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side