

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☒ OTHER		7. UNIT AGREEMENT NAME CONE 46771
2. NAME OF OPERATOR Beta Development Company		8. FARM OR LEASE NAME L. E. Fogelson 25
3. ADDRESS OF OPERATOR 125 Petroleum Club Plaza, Farmington, New Mexico		9. WELL NO.
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface South East 790 from North; 790 from South, Section 25-30N-11W		10. FIELD AND POOL, OR WILDCAT Blanca Basin Dakota
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 25-30N-11W
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5973' GL.		12. COUNTY OR PARISH San Juan
		13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug and abandon this well as follows:

Load hole with water, circulate out drilling mud & shale, clean out to T.D. 6920'; spot 50 sx. cement plug in bottom of 5 1/2" casing to cover all Dakota perforations; pull tubing up hole and pump 15 sx. cement at base of Gallup, 6250'; pull tubing up hole, put 15 sx. plug at base of Joint Lockout, 5350'; pull tubing up hole and put 15 sx. plug at base of Pictured Cliffs & O.V. Tool at 2604'; pull tubing out of hole and try to pull casing at this point. If unable to pull casing below the base of the Ojo Alamo will perforate with 2 1/2" holes and squeeze 20 sx. into formation. If casing comes below Ojo Alamo will pump 15 sx. plug in casing stub then 30 sx. at 1170', 10sx. in bottom of surface pipe at 731', and 10 sx. plug in top of surface pipe, with marker.



18. I hereby certify that the foregoing is true and correct

SIGNED E. E. Bryant

TITLE Superintendent

DATE March 15, 1971

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963-O-685229



1224

2000