

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Taylor
9. Well No. 1
10. Field and Pool, or Wildcat Aztec P.C.
12. County San Juan

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-
2. Name of Operator El Paso Natural Gas Company
3. Address of Operator P. O. Box 990, Farmington, New Mexico 87401
4. Location of Well UNIT LETTER 0, 1000 FEET FROM THE south LINE AND 1700 FEET FROM THE east LINE, SECTION 17 TOWNSHIP 30N RANGE 11W NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 5682' DF

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work; SEE RULE 1103.

Pull tubing, replace with 2 3/8" work string.
Spot cement plug in open hole. Fill from TD to 1900' with 22 sacks.
Pull out of hole and shoot squeeze holes across the Ojo Alamo. Perforate @ 735'
Spot cement plug across the Ojo Alamo interval and pull out of hole. Fill 100' in & out w/30 sx
Perforate squeeze holes at base of surface pipe. Spot cement plug and
pressure displace cement into formation and to the surface. Perforate @ 100' cement w/ 30 sx.
Set dry hole marker with 10 sx. Marker may be screwed onto 5 1/2 casing.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John J. Tellerson

TITLE Production Engineer

DATE 9-26-78

APPROVED BY AK Kendrick

TITLE Commissioner

DATE OCT 12 1978

CONDITIONS OF APPROVAL, IF ANY:

Telephone to advise of operations start at least 24 hours in advance.