

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF081299-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

J. J. Lommori "A"

8. FARM OR LEASE NAME

NE Hogback Unit

9. WELL NO.

13

10. FIELD AND POOL, OR WILDCAT

Horseshoe Gallup

11. SEC., T., R., M., OR BLE. AND
SURVEY OR AREA

Sec. 13-T30N-R16W

12. COUNTY OR PARISH

San Juan

13. STATE

N. Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL
WELL ☐GAS
WELL ☐OTHER ☐

Water Injection Well

2. NAME OF OPERATOR

Clinton Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 2434 - Casper, Wyoming 82601

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface

2140' FNL and 520' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5397' GL

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*Casing: 8-5/8" set at 217' w/160 sacks cement
5-1/2" set at 3813' w/130 sacks cementPerf: 3574'-3614' Upper Gallup
3681'-3703' Lower Gallup

Baker Model "N" packer set at 3662'

Propose to squeeze 25sacks of cement down tubing below packer

Place 20 sack cement plug 3662'-3512'

Shoot off 5-1/2" casing. Pull and lay down

Place 25 sack cement plug 50' inside and 50' above 5-1/2" casing stub

Place 50 sack cement plug 2000'-1850' (Pt. Lookout 1900'-2360')

Place 30 sack cement plug 510'-410' (Menefee 460'-1900')

Place 20 sack cement plug 217'-167'

Place 10 sack cement plug 30'-GL

Install dry hole marker

Clean up location

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

