

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

070 FARMINGTON, NM

5. Lease Designation and Serial No.
NM 021127

6. If Indian, Allottee or Tribe Name

30-045-10267

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Stanolind A

9. API Well No.

2

10. Field and Pool, or Exploratory Area

Basin Dakota

11. County or Parish, State

San Juan / New Mexico

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Cross Timbers Operating Company

3. Address and Telephone No.

6001 Highway 64, Farmington, New Mexico 87401 505 632 5200

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1190' FSL, 1850' FEL, SECTION 29, T 31 N, R 12 W

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The well will be plugged & abandoned in the following manner. Spot a 295 sx cement plug from 2,357'. Displace plug to 1,500'. WOC 2.5 hrs. Tag top of cement. If required spot a cement plug to fill inside and outside of csg to 1,500'. Perforate 4 squeeze holes @ 1,500'. Establish circulation. If circulation is established, circulate cement to surface (approximately 410 sx). Cut off and install a dry hole marker with 10 sx cement. If unable to circulate adequately, spot a 100' cmt plug inside & out with 50 sx cement. WOC 2.5 hrs. Perforate 4 squeeze holes @ 798'. Spot a 105 sx cement plug inside and outside the csg from 798' to 571'. WOC 2.5 hrs. Perforate 4 squeeze holes @ 405' and circulate a 125 sx cmt plug to surface. Cut off and install a dry hole marker with 10 sx cement.

Verbal approval was given by BLM representative Stephen Mason at 1:30 pm, 6/30/98.

RECEIVED
JUL 17 1998
OIL CON. DIV.
DIST. 3

14. I hereby certify that the foregoing is true and correct

Signed Loren W. Fechenig

Title Production Engineer

Date 06/30/98

(This space for Federal or State office use)

Approved by /S/ Duane W. Spencer

Title

Date JUL 14 1998

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

NMOC