

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

50. Indicate Type of Lease
State ☐ Fee ☒

51. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Amoco Production Company	8. Farm or Lease Name Leeper Gas Com "D"
3. Address of Operator 501 Airport Drive, Farmington, New Mexico 87401	9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> <u>1480</u> FEET FROM THE <u>South</u> LINE AND <u>800</u> FEET FROM THE <u>West</u> LINE, SECTION <u>34</u> TOWNSHIP <u>32N</u> RANGE <u>10W</u> N.M.P.M.	10. Field and Pool, or Wildcat Mt. Nebo Fruitland
15. Elevation (Show whether DF, RT, GR, etc.) 5838' GL	12. County San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Plug and abandonment</u> <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Amoco Production Company requests confirmation of the verbal approval given by Charles Giddis, of your office, to Mickey O'Hare, of this office, on 1-26-84 to plug and abandon the above referenced well according to the following procedures:

1. Spot 185 SX Class "B" cement with 2% CaCl₂ from 663'-345'.
2. Pull drill string up to 345' and circulate with 12.6 ppg mud for 2-3 hours.
3. Spot 183 SX Class "B" cement with 2% CaCl₂ from 345'-surface.
4. Trip out with drill string.
5. Hook up to the braden head and pump 8 bbls. of Class B with 2% CaCl₂.
6. Cut off casing below the surface and weld on PXA marker.

RECEIVED

JAN 30 1984

OIL CON. DIV.

DIST. 3

CONFIDENTIAL

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed By
D.D. Lawson

TITLE District Adm. Supervisor

DATE January 26, 1984

Original Signed by CHARLES GHOLSON

TITLE DEPUTY OIL & GAS INSPECTOR, DIST. #2

DATE JAN 30 1984

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY: