

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT - " for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> WIW		5. LEASE DESIGNATION AND SERIAL NO. LC-029419-A✓	
2. NAME OF OPERATOR The Wiser Oil Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P.O. Box 2568 Hobbs, New Mexico 88241		7. UNIT AGREEMENT NAME Skelly Unit	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) ✓ surface ✓ 660' FNL & 1880' FEL Unit B		8. WELL NAME AND NO. 42	
		9. API WELL NO. 30-015-05356	
		10. FIELD AND POOL, OR WILDCAT Grayburg Jackson 7-Rivers-QN-GB-SA	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 22-T17S-R31E✓	
14. PERMIT NO	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3875' DF	12. COUNTY OR PARISH Eddy County	13. STATE NM

16. Check Appropriate Box to indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>

(Other) Plug and Abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT * <input type="checkbox"/>
(Other) <input type="checkbox"/>	

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Wiser requests approval to Plug and Abandon the well by the procedure listed below.

Surface Casing: 8-5/8" set @ 616' ✓ Production Casing: 4-1/2" set @ 3764' 11.60#

Perfs: 3188'-3606' 2283'-2400' CIBP @ 2100' & 3106' with 40' cement on plug ✓

- Spot 50' plug on CIBP @ 2100'.
- Tag cement plug.
- Circulate abandonment mud.
100' (25' 5X)
- Spot 50' cement plug @ 1600' to 1550'. 1700'
- Tag cement plug.
- Perforate casing @ 620' & circulate cement to surface. Leave a 50' plug @ 620' to 570'.
100' 606 - 566'
- Tag cement.
60'
- Spot 50' cement plug to surface.
- Install dry hole marker.
- Clean location.

APPROVAL SUBJECT TO
GENERAL REQUIREMENTS AND
SPECIAL STIPULATIONS ATTACHED

18. I hereby certify that the foregoing is true and correct.

SIGNED

Alexis C. Swoboda

TITLE Prod. Supt.

DATE April 1, 2003

(This space for Federal or State office use)

APPROVED BY

Alexis C. Swoboda

PETROLEUM ENGINEER

DATE

APR 08 2003

CONDITIONS OF APPROVAL, IF ANY:

*See Instruction On Reverse Side

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Alexis C. Swoboda

APR 14 2003

ENTERED IN
AFMSS

Est.

Geol. Tcps per Box / cpr

Rustler 330'

Salado 620'

BX 1595'

Gates 1768'

Turns 2105'

Bower 2400'

Queen 2716'

Grayburg 3104'

San Andres 3457'

851 616

8-19-88

Pipe Analysis

0-2165

30-015-05356

WIW Order # R-4717A Fren SR

WIW

order # L-2900

L-3214