<u>District 1</u> 1625 N. French Dr., Hobbs, NM 88240 Phone: (513) 393-6161 Faz: (575) 393-0720 <u>District II.</u> 811 S. Farst St., Artesia, NM 88210 Phone: (515) 748-1225 Faz: (575) 748-9720 <u>District III.</u> 1000 Rio Brazos Road, Axtee, NM 87410 <u>Phone: (505) 334-6178 Faz: (505) 334-6170 <u>District IV.</u> 1220 S. S. Francis Dr., Satia Fe, NM 87505 Phone: (505) 476-3460 Faz: (505) 476-3462</u> State of New Mexico Energy, Minerals & Natural Resources Department OIL CONSERVATION DIVISION 1220 South St. Francis Dr. Santa Fe, NM 87505 Form C-102 Revised August 1, 2011 Submit one copy to appropriate District Office

☐ AMENDED REPORT

			WEL	LOCA	TIC	<u>N ANI</u>	ACK	EAGE D	EDICATIO	NPLAT	3		·· .
	API	Number	711		Pool C	ode		Pool Name					
30-0	15-	4115	6687   ISOIL					Culebra Bluff Bone Spring, South					
Property Code Pro						Property	Name		,		ห	/ell Number	
40	791					VILLA	A FE	CE COM					<u>2</u> H
OGRID No. Op						Operator	Name					Elevation	
192463 OXY USA									3	032.4'			
Surface Location													
UL or lot no.	Section	Township	ľ	Rai	nge		Lot Idn	Feet from the	North/South line	Feet from the	East/We	est line	County
L	8	23 SOUTI	1 2	8 EAST,	N M	. <b>Р. М</b> .		2290'	SOUTH	250'	WES	T	EDDY
,	4	······	<u>ينديات.</u> لا	Bottom	Hole	Locati	on If I	Different I	From Surfac	e	L		
UL or lot no.	Section	Township	·	Ra	nge		Lot Ida	Feet from the	North/South line	Feet from the	East/We	est line	County
I	8	23 SOUTI	I 2	8 EAST,	N. M	(. P. M.		1704'	SOUTH	190'	EAS	ST	EDDY
Dedicated	Acres	Joint or Infill	Cons	olidation Co	de	Order No.	•				•		
160 N													
No allowa	ble wil	l be assigned	to this	completic	n' unt	il all inter	ests ha	ve heen con	solidated or a	non-standaro	l unit has l	heen ann	roved by the

No allowable will be assigned to this completion until all interests have been consolidated or a non-standard unit has been approved by the division.



Operator Name/Number: OXY USA WTP LP										192463	
Lease	e Name/Nu	mber:	Villa A Fee	e Com #2H							
Pool	Name/Num	nber:	Culebra B	uff Bone S	pring, South	pring, South 15011					
Surfa	ce Locatio	n:									
Тор Г	Perf:		2040 FSL	716 FWL 1	_ Sec 8 T235	6 R28E					
Botto	om Perf:		1705 FSL	330 FEL 1	Sec 8 T23S	R28E					
Botto	om Hole Lo	cation:	1704 FSL	190 FEL I	Sec 8 T23S	R28E					
C-102	2 Plats:	9/17/13	3/31/14	3/31/14 Elevation: <u>3032.4' GL</u>					Objective: 3rd Bone Spring		
Proposed TD: Horizontal Lateral 9319' TVD 13906' TMD							TMD				
SL - I	_at: 32.318	7262 Long	: 104.116844	45	X=479736.5	Y=56	6877.3	NAD - 1927			
TP - I	_at: 32.318	0407 Long	: 104.11534	104.1153450 X=479488.1 Y=567341.0				NAD - 1927			
BP - I	Lat: 32.317	1486 Long	: 104.10168	28	X=479172.4 Y=571562.3		1562.3	NAD - 1927			
BH - 1	Lat: 32.317	1478 Long	: 104.10123	09	X=479172.4	Y=57	1701.8		NAD - 192	7	
Casir	ng Program	1:									
	Hole	<u>Interval</u>	OD Csg	<u>Weight</u>	<u>Collar</u>	<u>Grade</u>	Condition	<u>Collapse</u>	<u>Burst</u>	<u>Tension</u>	
	Size							<u>Design</u>	<u>Design</u>	Design	
							·	Factor	Factor	Factor	
	14-3/4"	0-400'	11-3/4"	47	BT&C	J55	New	8.57	1.43	6.38	
			Hole fil			th 8.5# Mu	ıd	1514#	3072#		

LT&C

Hole filled with 10.2# Mud

J-55

New

3.06

2533#

1.68

7477#

1.33

3928#

1.23

10640#

2.5

2.31

7-7/8" 0-13906' 5-1/2" 17 BT&C P-110 New Hole filled with 9.2# Mud

32

Collapse and burst loads calculated using Stress Check with anticipated loads

8-5/8"

#### **Cement Program:**

10-5/8"

0-2500'

a. 11-3/4"	Surface	Circulate cement to surface w/ 320sx PPC cmt w/ 2% CaCl2, 14.8ppg 1.35 yield 1500# 24hr CS 125% Excess
b. 8-5/8"	Intermediate	Circulate cement to surface w/ 420sx HES Light PPC cmt w/ 5% salt + .125#/sx Poly-E- Flake + 2#/sx Kol-Seal, 12.9ppg 1.89 yield 700# 24hr CS 100% Excess followed by 170sx PPC cmt w/ 1% CaCl2, 14.8ppg 1.33 yield 2100# 24hr CS 100% Excess
c. 5-1/2"	Production	Cement w/ 710sx PP cmt w/ 14.8#/sx Silicalite 50/50 Blend + 15#/sx Scotchlite HGS-6000 + 3#/sx Kol-Seal + .125#/sx Poly-E-Flake + .25#/sx HR-800, 10.2ppg 2.95 yield 900# 24hr CS 100% Excess followed by 790sx Super H cmt w/ 3#/sx salt + .4% CFR-3 + .5% Halad-344 + .3% HR-800 + .125#/sx Poly-E-Flake, 13.2ppg 1.66 yield 620# 24hr CS 40% Excess. Calc TOC-1500'
Descriptio	on of Cement	Additives: Calcium Chloride, Salt (Accelerator); Silicalite (Additive Material);

CFR-3 (Dispersant); Bentonite, Schotchlite HGS-6000 (Light Weight Additive);

Kol-Seal, Poly-E-Flake (Lost Circulation Additive); Halad-344 (Low Fluid Loss Control); HR-601, HR-800 (Retarder) The above cement volumes could be revised pending the caliper measurement.

#### **Proposed Mud Circulation System:**

Depth	Mud Wt.	<u>Visc</u> sec	<u>Fluid</u> Loss	Type System	
0 - 400'	8.4-8.8	32-34	NC	Fresh Water/Spud Mud	
400 - 2500'	9.6-10	28-32	. NC	Fresh water/NaCl Brine	
2500 - KOP	9.2	28-32	NC	Cut Brine/Sweeps	
KOP - TD	9.2	32-50	<18	Cut Brine/Sweeps	

Pump high viscosity sweeps as needed for hole cleaning. The mud system will be monitored visually/manually as well as with an electronic PVT. The necessary mud products for additional weight and fluid loss control will be on location at all times. Appropriately weighted mud will be used to isolate potential gas, oil, water zones until such time as casing can be cemented into place for zonal isolation.

BOP Program:

Surface	None
Intermediate/Production	13-5/8" 10M three ram stack w/ 5M annular preventer, 5M Choke Manifold

#### Estimated Tops of Geological Markers & Depths of Anticipated Fresh Water, Oil or Gas:

Geological Marker	<u>Depth</u>	Type
a. Rustler	272'	
b. Top Salt	326'	
c. Delaware/Lamar	2433'	Formation
d. Bell Canyon	2501'	Oil/Gas
e. Cherry Canyon	3319'	Oil/Gas
f. Brushy Canyon	4434'	Oil/Gas
g. Bone Spring	5993'	Oil/Gas
h. 2nd Bone Spring	7102'	Oil/Gas
i. 3rd Bone Spring	7906'	Oil/Gas
j. Wolfcamp	9352'	Oil/Gas

Fresh water may be present above the Rustler formation. Surface casing will be set below the top of the Rustler, which will cover potential fresh water sources.

A closed loop system will be utilized consisting of above ground steel tanks and haul-off bins. Disposal of liquids, drilling fluids and cuttings will be disposed of at an approved facility.





# LOCATION VERIFICATION MAP



VICINITY MAP







# Weatherford International Ltd. WFT Plan Report - X & Y's



Company: Occidental Pe Field: Eddy Co, NM Site: Villa A Fee Co Well: Villa A Fee Co Wellpath: 1	rmian Ltd. (Nad,27) om #2H om #2H	D. C. V. Sč St	ate: 3/25/2014 T o-ordinate(NE) Reference: ertical (TVD) Reference: rction (VS) Reference: irvey Calculation Method:	ime: 07:36:23 Well: Villa A Fe SITE, 3056:4 Well-(0.00N,0 Minimum Curv	Page: I ee Com #2H, Grid North 00E!96:90Azi) ature Db: Sybase
Plan: Plan #6			Date Composed: Version: Tied-to:	3/19/2014 1 Erom Surface	
Site: Villa A Fee 0	Com #2H				
Site Position: From: Map Position Uncertainty:	Northing Easting: 0.00 ft 3032.40 ft	g: 479736.50 ft 566877.30 ft	Latitude: 32 Longitude: 104 North Reference: Crid Convergence:	19 7.414 N 7 0.640 W Grid	
Well: Villa A Fee (	Com #2H		Slot Name:	0.12 deg	
Well Position: +N/-5 +E/-V Position Uncertainty:	S 0.00 ft Northing W 0.00 ft Easting 0.00 ft	g: 479736.50 ft 566877.30 ft	Latitude: 32 Longitude: 104	19 7.414 N 7 0.640 W	
Wellpath: 1 Current Datum: SITE Magnetic Data: Field Strength: Vertical Section: Depth	6/1/2014 48343 nT From (TVD) ft	Height 3056.40 ft +N/-S ft	Drilled From: Tie-on Depth: Above System Datum: Declination: Mag Dip Angle: +E/-W ft	Surface 0.00 ft Mean Sea Level 7.48 deg 60.11 deg Direction deg	
(	0.00	0.00	0.00	96.90	
Plan Section Information					
MD Find ft deg	Azim TVD deg ft	+N/-S +E/-W ft ft	DLS Build 1 deg/100ft.deg/100ft.de	urn TFO g/100ft deg	Target
0.00         0.00           8599.00         0.00           9582.22         88.49           10709.41         88.95           13906.09         88.95	0.00         0.00           0.00         8599.00           118.18         9235.40           90.00         9261.06           90.00         9319.40	0.00         0.00           0.00         0.00           -292.72         546.37           -564.24         1628.39           -564.07         4824.54	0.00 0.00 0.00 0.00 9.00 9.00 2.50 0.04 - 0.00 0.00	0.00         0.00           0.00         0.00           0.00         118.18           2.50         -89.40           0.00         0.00	PBHL
Survey					
MD Incl Az	zim TVD N/ deg ft f	S E/W ft	VS DLS ft deg/100ft	MapN I ft	MapE . Comment .ft
$\begin{array}{cccc} 0.00 & 0.00 \\ 100.00 & 0.00 \\ 200.00 & 0.00 \\ 300.00 & 0.00 \\ 400.00 & 0.00 \end{array}$	0.00         0.00           0.00         100.00           0.00         200.00           0.00         300.00           0.00         400.00	0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00	0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00	479736.50 479736.50 479736.50 479736.50 479736.50 479736.50	566877.30 566877.30 566877.30 566877.30 566877.30 566877.30
$\begin{array}{cccc} 500.00 & 0.00 \\ 600.00 & 0.00 \\ 700.00 & 0.00 \\ 800.00 & 0.00 \\ 900.00 & 0.00 \end{array}$	0.00         500.00           0.00         600.00           0.00         700.00           0.00         800.00           0.00         900.00	0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00	0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00	479736.50 479736.50 479736.50 479736.50 479736.50 479736.50	566877.30 566877.30 566877.30 566877.30 566877.30 566877.30
$\begin{array}{cccc} 1000.00 & 0.00 \\ 1100.00 & 0.00 \\ 1200.00 & 0.00 \\ 1300.00 & 0.00 \\ 1400.00 & 0.00 \end{array}$	0.00         1000.00           0.00         1100.00           0.00         1200.00           0.00         1300.00           0.00         1400.00	0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00	0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00	479736.50 479736.50 479736.50 479736.50 479736.50 479736.50	566877.30 566877.30 566877.30 566877.30 566877.30 566877.30
1500.000.001600.000.001700.000.001800.000.001900.000.00	0.00         1500.00           0.00         1600.00           0.00         1700.00           0.00         1800.00           0.00         1900.00	0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00	0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00           0.00         0.00	479736.50 479736.50 479736.50 479736.50 479736.50 479736.50	566877.30 566877.30 566877.30 566877.30 566877.30 566877.30
2000.00 0.00 2100.00 0.00	0.00 2000.00 0.00 2100.00	0.00 0.00 0.00 0.00	0.00 0.00 0.00 0.00	479736.50 479736.50	566877.30 566877.30



Survey

### Weatherford International Ltd. WFT Plan Report - X & Y's



Company: Occidental Rermian Ltd: Field: Eddy Co, NM (Nad 27) Site: Villa A Fee Com #2H Well: Villa A Fee Com #2H Wellpath: 1

 Date:
 3/25/2014
 Time:
 07.36.23
 Page:
 2

 Co-ordinate(NE)
 Reference:
 Well
 Villa A Fee Com #2H Grid North

 Vertical (TVD)
 Reference:
 SITE 3056.4

 Section (VS)
 Reference:
 Well
 0:00N 0.00E 96.90Azi)

 Survey Calculation Method:
 Minimum Curvature
 Db:
 Sybase

, s MD ft	Incl deg	Azim deg	TVD ft	N/S ft	E/W ft	VS ft`⊡d	DLS eg/100ft	MapN ft	MapE ft	🔩 Commen
2200.00	0.00	0.00	2200.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
2300.00	0.00	0.00	2300.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
2400.00	0.00	0.00	2400.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
2500.00	0.00	0.00	2500.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
2600.00	0.00	0.00	2600.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
2700.00	0.00	0.00	2700.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
2800.00	0.00	0.00	2800.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
2900.00	. 0.00	0.00	2900.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3000.00	0.00	0.00	3000.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3100.00	0.00	0.00	3100.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3200.00	0.00	0.00	3200.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3300.00	0.00	0.00	3300.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3400.00	0.00	0.00	3400.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3500.00	0.00	0.00	3500.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3600.00	0.00	0.00	3600.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3700.00	0.00	0.00	3700.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3800.00	0.00	0.00	3800.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
3900.00	0.00	0.00	3900.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4000.00	0.00	0.00	4000.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4100.00	0.00	0.00	4100.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4200.00	0.00	0.00	4200.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4300.00	0.00	0.00	4300.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4400.00	0.00	0.00	4400.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4500.00	0.00	0.00	4500.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4600.00	0.00	0.00	4600.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4700.00	0.00	0.00	4700.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4800.00	0.00	0.00	4800.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
4900.00	0.00	0.00	4900.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5000.00	0.00	0.00	5000.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5100.00	0.00	0.00	5100.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5200.00	0.00	0.00	5200.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5300.00	0.00	0.00	5300.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5400.00	0.00	0.00	5400.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5500.00	0.00	0.00	5500.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5600.00	0.00	0.00	5600.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5700.00	0.00	0.00	5700.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5800.00	0.00	0.00	5800.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
5900.00	0.00	0.00	5900.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6000.00	0.00	0.00	6000.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6100.00	0.00	0.00	6100.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6200.00	0.00	0.00	6200.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6300.00	0.00	0.00	6300.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6400.00	0.00	0.00	6400.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6500.00	0.00	0.00	6500.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6600.00	0.00	0.00	6600.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6700.00	0.00	0.00	6700.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6800.00	0.00	0.00	6800.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
6900.00	0.00	0.00	6900.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
7000.00	0.00	0.00	7000.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
7100.00	0.00	0.00	7100.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
7200.00	0.00	0.00	7200.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
7300.00	0.00	0.00	7300.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
7400.00	0.00	0.00	7400.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
L						·····				



### Weatherford International Ltd. WFT Plan Report - X & Y's

Company: Occidental Permian Ltd. Date: 3/25/2014 - Time: 07/36:23 Page: 3



Field:	ddy Co; Illa A Fe	NM (Nad 2 e Com #2F	27)			Co-ordinate()	NE) Reference	Well: Villa	A Fee Com #2H	Grid North
Well: V	illa A Fe	e Com #21	i se ces			Section (VS)	Reference:	Well (0.001	N,0.00E,96.90Az	zi)
Wellpath: 1						Survey Galcu	lation Method	I: Minimum G	Curvature	Db: Sÿbasè
Survey							<u></u>			
MD	Incl	Azim	TVD	N/S MORE	FAV	* VC		ManN	ManE	Comment
S. ft MA	, dea'	dea	ft	,	ft.	ft	dea/100ft	ft	ft	Comment
and a start of the second s		The America, Albert				is the restances of	ta a Stan marting			
7500.00	0.00	0.00	7500.00	0.00	0.00	0.00	0.00	479736 50	566877 30	
7600.00	0.00	0.00	7600.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
7700.00	0.00	0.00	7700.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
7800.00	0.00	0.00	7800.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
7900.00	0.00	0.00	7900.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
8000.00	0.00	0.00	8000.00	0.00	0.00	0.00	0.00	470720 50	500077.00	
8100.00	0.00	0.00	8100.00	0.00	0.00	0.00	0.00	479736.50	566877 30	
8200.00	0.00	0.00	8200.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
8300.00	0.00	0.00	8300.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
8400.00	0.00	0.00	8400.00	0.00	0.00	0.00	0.00	479736.50	566877.30	
0500.00										
8500.00	0.00	0.00	8500.00	0.00	0.00	0.00	0.00	479736.50	566877.30	KOD
8650.00	4.50	118 18	8640.05	0.00	0.00	0.00	0.00	479736.50	566877.30	KUP
8700.00	9.09	118 18	8699 58	-3.78	7.05	7 45	9.00	479732.04	566884 35	
8750.00	13.59	118.18	8748.59	-8.42	15.71	16.61	9.00	479728.08	566893.01	
8800.00	18.09	118.18	8796.68	-14.86	27.74	29.32	9.00	479721.64	566905.04	
8850.00	22.59	118.18	8843.55	-23.07	43.05	45.51	9.00	479713.43	566920.35	
8900.00	27.09	118.18	8032 40	-32.98	61.56 83.15	65.08 97.00	9.00	479703.52	566938.86	
9000.00	36.09	118.18	8974.00	-57.69	107.69	113.84	9.00	479678 81	566984 99	
				01100		110.01	0.00	110070.01	000004.00	
9050.00	40.59	118.18	9013.21	-72.34	135.02	142.74	9.00	479664.16	567012.32	
9100.00	45.09	118.18	9049.86	-88.39	164.98	174.41	9.00	479648.11	567042.28	
9150.00	49.59	118.18	9083.74	-105.75	197.39	208.66	9.00	479630.75	567074.69	
9200.00	54.09	118.18	9114.62	-124.31	232.03	245.29	9.00	479612.19	567109.33	
9250.00	56.59	110.10	9142.33	-143.90	200.71	204.00	9.00	479592.54	367146.01	
9300.00	63.09	118.18	9166.69	-164.57	307.18	324.73	9.00	479571.93	567184.48	
9350.00	67.59	118.18	9187.54	-186.03	347.23	367.06	9.00	479550.47	567224.53	
9400.00	72.09	118.18	9204.77	-208.19	388.59	410.79	9.00	479528.31	567265.89	
9450.00	76.59	118.18	9218.26	-230.92	431.02	455.64	9.00	479505.58	567308.32	
9500.00	81.09	118.18	9227.94	-254.08	474.25	501.34	9.00	479482.42	567351.55	
9550.00	85 59	118 18	9233 73	-277 52	518.01	547 60	9.00	470458 08	567305 31	
9582.22	88.49	118.18	9235.40	-292.72	546.37	577.58	9.00	479443.78	567423.67	LP/Turn
9600.00	88.49	117.74	9235.87	-301.05	562.07	594.17	2.50	479435.45	567439.37	
9700.00	88.52	115.23	9238.47	-345.63	651.54	688.34	2.50	479390.87	567528.84	
9800.00	88.55	112.73	9241.02	-386.26	742.87	783.89	2.50	479350.24	567620.17	
9900 00	88 59	110 23	9243 51	-422 87	835.88	880.63	2 50	479313 63	567713 18	
10000.00	88.62	107.73	9245.95	-455.39	930.41	978.38	2.50	479281.11	567807.71	
10100.00	88.66	105.23	9248.31	-483.75	1026.26	1076.95	2.50	479252.75	567903.56	
10200.00	88.71	102.73	9250.61	-507.90	1123.27	1176.15	2.50	479228.60	568000.57	
10300.00	88.75	100.23	9252.83	-527.80	1221.23	1275.80	2.50	479208.70	568098.53	
10400.00	88 80	07 73	0254 07	543 41	1210.09	1275 70	2.50	470102.00	569107.09	
10500.00	88 84	95.23	9257.03	-554 70	1419.31	1475.67	2.50	479193.09	568296.61	
10600.00	88.90	92.73	9259.00	-561.64	1519.04	1575.51	2.50	479174.86	568396.34	
10709.41	88.95	90.00	9261.06	-564.24	1628.39	1684.38	2.50	479172.26	568505.69	Hold
10800.00	88.95	90.00	9262.71	-564.24	1718.97	1774.30	0.00	479172.26	568596.27	
10000.00	00.05	00.00	0004.50	504.00	4040.05	4070 50	0.00	170170		
11000.00	00.95 88.05	90.00 90.00	9204.53 9266 26	-504.23	1010.95	10/3.56	0.00	479172.27	568696.25	
11100.00	88.95	90.00	9268 18	-564 22	2018 92	2072.02	0.00	413112.21	568896 22	
11200.00	88.95	90.00	9270.01	-564.22	2118.90	2171.34	0.00	479172.28	568996.20	
11300.00	88.95	90.00	9271.84	-564.21	2218.88	2270.59	0.00	479172.29	569096.18	
11400.00	88.95	90.00	9273.66	-564.21	2318.87	2369.85	0.00	479172.29	569196.17	
11500.00	00.90	90.00	9210.49	-004.20	2410.00	2409.11	0.00	4/91/2.30	209290.15	



## Weatherford International Ltd. WFT Plan Report - X & Y's



Company: C Field: E Site: A Well: Wellpath: 1	Occidenta ddy Co,- /illa A Fe /illa A Fe	l'Permian NM (Nad 2 e Com #2F e Com #2F	Ltd: :7) -1 -1			Date: 3/25/2 Co-ordinate(N Vertical (TVD Section (VS) R Survey Calcul	2014: E) Reference: ) Reference: (cference: ation:Method	Time: 07:36:23 Well, Villa / SITE 3056 Well (0:00N I: Minimum.C	8 1 Fee Com #2H, C 4 1 0 00E 96 90Azi) urvature D	age: 4 Grid North bb: Sybase
Survey					<u> </u>					
MD ft,	Incl deg	Azim deg	TVD ft	N/S ft	E/W- ft	VS ft c	DLS deg/100ft	MapN ft	MapE ft	Comment
11600.00	88.95	90.00	9277.31	-564.19	2518.83	2568.37	0.00	479172.31	569396.13	
11700.00 11800.00	88.95 88.95	90.00 90.00	9279.14 9280.96	-564.19 -564.18	2618.82 2718.80	2667.63 2766.89	0.00 0.00	479172.31 479172.32	569496.12 569596.10	
11900.00	88.95	90.00	9282.79	-564.18	2818.78	2866.15	0.00	479172.32	569696.08	
12000.00	88.95	90.00	9284.61	-564.17	2918.77	2965.40	0.00	479172.33	569796.07	
12100.00	88.95	90.00	9286.44	-564.17	3018.75	3064.66	0.00	479172.33	569896.05	
12200.00	88.95 88.95	90.00 90.00	9288.26 9290.09	-564.16 -564.16	3118.73 3218.72	3163.92 3263.18	0.00	479172.34 479172.34	569996.03 570096.02	
12400.00	88.95	90.00	9291.91	-564.15	3318.70	3362.44	0.00	479172.35	570196.00	
12500.00	88.95	90.00	9293.74	-564.15	3418.68	3461.70	0.00	479172.35	570295.98	
12600.00	88.95	90.00	9295.56	-564.14	3518.67	3560.95	0.00	479172.36	570395.97	
12700.00	88.95	90.00	9297.39	-564.14	3618.65	3660.21	0.00	479172.36	570495.95	
12800.00	88.95	90.00	9299.21	-564.13	3718.63	3759.47	0.00	479172.37	570595.93	
12900.00	88.95	90.00	9301.04	-564.12	3818.62	3858.73	0.00	479172.38	570695.92	
13000.00	88.95	90.00	9302.86	-564.12	3918.60	3957.99	0.00	479172.38	570795.90	
13100.00	88.95	90.00	9304.69	-564.11	4018.58	4057.25	0.00	479172.39	570895.88	
13200.00	88.95 88.95	90.00 90.00	9306.51 9308.34	-564.11	4118.57 4218.55	4156.51 4255.76	0.00	479172.39	5710995.85	
10,400,000	00.05	00.00	0040.40	504.40	4040.50	4055.00	0.00	170170 10	571405.00	
13400.00	88.95	90.00	9310.16	-564.10	4318.53	4355.02	0.00	479172.40	571195.83	
13600.00	88 95	90.00	9311.99	-564.09	4410.52	4404.20	0.00	479172.41	571395.02	
13700.00	88.95	90.00	9315.64	-564.08	4618 48	4652.80	0.00	479172.47	571495 78	
13800.00	88.95	90.00	9317.46	-564.08	4718.47	4752.06	0.00	479172.42	571595.77	
13906.09	88.95	90.00	9319.40	-564.07	4824.54	4857.36	0.00	479172.43	571701.84 F	BHL
Tangata								••••		
Targets		UNK KOM	APPENDING PART	60) (		(Telephone and	N	The second s		and the state of the second second
Name	5.53	Descripti	on >T	/D +N	N/-S	/-W Nort	ip thing Eas	ap < La ting Deg Mii	n Sec Deg	Min Sec
		Dip.	Dir: 👾 f	t sa t	ft	ft:	t 🖓 🖒 🕺 ft			
PBHL	Construction	1.37	89.74 9319	.40 -56	4.07 4824	1.54 4791	72.43 57170	01.84 32 19	1.732 N 104	6 4.431 W
Casing Poin	ts 	NEW TO STREET, DOWN	ander is an inter a survey of the latter water a	WIN ARTIGUTUTUTUTUTUTUTUTUTUTUTUTUTUTUTUTUTUTU	No Line - And - Constant Street & March	a an addition to an addition of the additional	THE MUTURE IN ADDRESS AND ADDRESS	10000 ATTEND - ODD THE HEADING VICE ACTION OF MANY AND LOC	NAPAGE STORES	There are not not the state and the second
MD	TVD	🖉 Diamo	ter 🔨 Hole	Size	Name				and an area in the	
					e parti este de la			<u>intera e 2008E</u> s		
			· · · ·		<u></u> .					
Annotation	a sublicities soft and the mag	NAME OF STREET, STREET, ST.	1971 - 2010 - 179 - 2010 - 2010 - 2010 - 2010	-Solen V. St. Patrick Mar. and St. So	642 MATER & WEIGHT 'N 199	. The state of the second state	a na ang ang ang ang ang ang ang ang ang	RANTER VIEW MANGANIAN OF STREET	and a second for the second second second second	
C. MD ft	∴TVD* ∛ft									
8599.00	8500 00	KOP	ton na se a remaine			Contraction in the	in an		S.C. S.	
9582.22	9235.40	LP/T	urn							
10709.41	9261.06	Hold								
13906.09	9319.40	PBHI	-							
Formations										
MD	TVD	For	mations			Lithology		C. 67° C. 75°	Dip Angle Dip	Direction
		$\mathcal{A}^{(1)}$								
A CONTRACTOR OF			and the second se				Comes and a stand of the	and the second	<ul> <li>Sector and the sector sector and the sector and the sector se</li></ul>	And Construction (N. Market State
L									· ··· ·· ··· ··· ··· ···	<u></u> _

















.

.



# Permian Drilling Hydrogen Sulfide Drilling Operations Plan New Mexico

#### <u>Scope</u>

This contingency plan establishes guidelines for the public, all company employees, and contract employees who's work activities may involve exposure to hydrogen sulfide (H2S) gas.

While drilling this well, it is possible to encounter H2S bearing formations. At all times, the first barrier to control H2S emissions will be the drilling fluid, which will have a density high enough to control influx.

#### **Objective**

- 1. Provide an immediate and predetermined response plan to any condition when H2S is detected. All H2S detections in excess of 10 parts per million (ppm) concentration are considered an Emergency.
- 2. Prevent any and all accidents, and prevent the uncontrolled release of hydrogen sulfide into the atmosphere.
- 3. Provide proper evacuation procedures to cope with emergencies.
- 4. Provide immediate and adequate medical attention should an injury occur.

### **Discussion**

**9**.

Implementation:	This plan with all details is to be fully implemented before drilling to <u>commence</u> .
Emergency response Procedure:	This section outlines the conditions and denotes steps to be taken in the event of an emergency.
Emergency equipment Procedure:	This section outlines the safety and emergency equipment that will be required for the drilling of this well.
Training provisions:	This section outlines the training provisions that must be adhered to prior to drilling.
Drilling emergency call lists:	Included are the telephone numbers of all persons to be contacted should an emergency exist.
Briefing:	This section deals with the briefing of all people involved in the drilling operation.
Public safety:	Public safety personnel will be made aware of any potential evacuation and any additional support needed.
Check lists:	Status check lists and procedural check lists have been included to insure adherence to the plan.
General information:	A general information section has been included to supply support information.

All personnel, whether regularly assigned, contracted, or employed on an unscheduled basis, will receive training from a qualified instructor in the following areas prior to commencing drilling operations on the well:

- 1. The hazards and characteristics of H2S.
- 2. Proper use and maintenance of personal protective equipment and life support systems.
- 3. H2S detection.
- 4. Proper use of H2S detectors, alarms, warning systems, briefing areas, evacuation procedures and prevailing winds.
- 5. Proper techniques for first aid and rescue procedures.
- 6. Physical effects of hydrogen sulfide on the human body.
- 7. Toxicity of hydrogen sulfide and sulfur dioxide.
- 8. Use of SCBA and supplied air equipment.
- 9. First aid and artificial respiration.
- 10. Emergency rescue.

In addition, supervisory personnel will be trained in the following areas:

- 1. The effects of H2S on metal components. If high tensile strength tubular is to be used, personnel will be trained in their special maintenance requirements.
- 2. Corrective action and shut-in procedures when drilling a well, blowout prevention and well control procedures.
- 3. The contents and requirements of the H2S Drilling Operations Plan.

H2S training refresher must have been taken within one year prior to drilling the well. Specifics on the well to be drilled will be discussed during the pre-spud meeting. H2S and well control (choke) drills will be performed while drilling the well, at least on a weekly basis. This plan shall be available in the well site. All personnel will be required to carry the documentation proving that the H2S training has been taken.

Service company and visiting personnel

- A. Each service company that will be on this well will be notified if the zone contains H2S.
- B. Each service company must provide for the training and equipment of their employees before they arrive at the well site.
- C. Each service company will be expected to attend a well site briefing

#### **Emergency Equipment Requirements**

#### 1. <u>Well control equipment</u>

The well shall have hydraulic BOP equipment for the anticipated pressures. Equipment is to be tested on installation and follow Oxy Well Control standard, as well as BLM Onshore Order #2.

Special control equipment:

- A. Hydraulic BOP equipment with remote control on ground. Remotely operated choke.
- B. Rotating head
- C. Gas buster equipment shall be installed before drilling out of surface pipe.

#### 2. <u>Protective equipment for personnel</u>

- A. Four (4) 30-minute positive pressure air packs (2 at each briefing area) on location.
- B. Adequate fire extinguishers shall be located at strategic locations.
- C. Radio / cell telephone communication will be available at the rig.
  - Rig floor and trailers.
  - Vehicle.

#### 3. <u>Hydrogen sulfide sensors and alarms</u>

- A. H2S sensor with alarms will be located on the rig floor, at the bell nipple, and at the flow line. These monitors will be set to alarm at 10 ppm with strobe light, and audible alarm.
- B. Hand operated detectors with tubes.
- C. H2S monitor tester (to be provided by contract Safety Company.)
- D. There shall be one combustible gas detector on location at all times.

#### 4. <u>Visual Warning Systems</u>

A. One sign located at each location entrance with the following language:

Caution – potential poison gas Hydrogen sulfide No admittance without authorization

)

#### *Wind sock – wind streamers:*

- A. One 36" (in length) wind sock located at protection center, at height visible from rig floor.
- B. One 36" (in length) wind sock located at height visible from pit areas.

#### Condition flags

A. One each condition flag to be displayed to denote conditions.

#### green – normal conditions yellow – potential danger red – danger, H2S present

B. Condition flag shall be posted at each location sign entrance.

#### 5. <u>Mud Program</u>

The mud program is designed to minimize the risk of having H2S and other formation fluids at surface. Proper mud weight and safe drilling practices will be applied. H2S scavengers will be used to minimize the hazards while drilling. Below is a summary of the drilling program.

#### Mud inspection devices:

Garrett gas train or hatch tester for inspection of sulfide concentration in mud system.

#### 6. <u>Metallurgy</u>

- A. Drill string, casing, tubing, wellhead, blowout preventers, drilling spools or adapters, kill lines, choke manifold, lines and valves shall be suitable for the H2S service.
- B. All the elastomers, packing, seals and ring gaskets shall be suitable for H2S service.

### 7. <u>Well Testing</u>

No drill stem test will be performed on this well.

8. <u>Evacuation plan</u>

Evacuation routes should be established prior to well spud for each well and discussed with all rig personnel.

- 9. Designated area
  - A. Parking and visitor area: all vehicles are to be parked at a predetermined safe distance from the wellhead.
  - B. There will be a designated smoking area.
  - C. Two briefing areas on either side of the location at the maximum allowable distance from the well bore so they offset prevailing winds perpendicularly, or at a 45-degree angle if wind direction tends to shift in the area.

#### **Emergency procedures**

- A. In the event of any evidence of H2S level above 10 ppm, take the following steps:
  - 1. The Driller will pick up off bottom, shut down the pumps, slow down the pipe rotation.
  - 2. Secure and don escape breathing equipment, report to the upwind designated safe briefing / muster area.
  - 3. All personnel on location will be accounted for and emergency search should begin for any missing, the Buddy System will be implemented.
  - 4. Order non-essential personnel to leave the well site, order all essential personnel out of the danger zone and upwind to the nearest designated safe briefing / muster area.
  - 5. Entrance to the location will be secured to a higher level than our usual "Meet and Greet" requirement, and the proper condition flag will be displayed at the entrance to the location.
  - 6. Take steps to determine if the H2S level can be corrected or suppressed and, if so, proceed as required.
- B. If uncontrollable conditions occur:
  - 1. Take steps to protect and/or remove any public in the down-wind area from the rig – partial evacuation and isolation. Notify necessary public safety personnel and appropriate regulatory entities (i.e. BLM) of the situation.

- 2. Remove all personnel to the nearest upwind designated safe briefing / muster area or off location.
- 3. Notify public safety personnel of safe briefing / muster area.
- 4. An assigned crew member will blockade the entrance to the location. No unauthorized personnel will be allowed entry to the location.
- 5. Proceed with best plan (at the time) to regain control of the well. Maintain tight security and safety procedures.
- C. Responsibility:

,

- 1. Designated personnel.
  - a. Shall be responsible for the total implementation of this plan.

 $\sim$ 

- b. Shall be in complete command during any emergency.
- c. Shall designate a back-up.

All personnel:	1.	On alarm, don escape unit and report to the nearest upwind designated safe briefing / muster area upw
	2.	Check status of personnel (buddy system).
	3.	Secure breathing equipment.
	4.	Await orders from supervisor.
Drill site manager:	1.	Don escape unit if necessary and report to nearest upwind designated safe briefing / muster area.
	2.	Coordinate preparations of individuals to return to point of release with tool pusher and driller (using the buddy system).
	3.	Determine H2S concentrations.
	4.	Assess situation and take control measures.
Tool pusher:	1.	Don escape unit Report to up nearest upwind
		designated safe briefing / muster area.
	2.	Coordinate preparation of individuals to return to
		(using the buddy system)
	3	Determine H2S concentration
	Δ.	Assess situation and take control measures
	-т.	rissess situation and take control measures.
Driller:	1.	Don escape unit, shut down pumps, continue

	2. 3. 4. 5.	rotating DP. Check monitor for point of release. Report to nearest upwind designated safe briefing / muster area. Check status of personnel (in an attempt to rescue, use the buddy system). Assigns least essential person to notify Drill Site Manager and tool pusher by quickest means in case of their absence. Assumes the responsibilities of the Drill Site Manager and tool pusher until they arrive should they be absent.
Derrick man Floor man #1 Floor man #2	1.	Will remain in briefing / muster area until instructed by supervisor.
Mud engineer:	1. 2.	Report to nearest upwind designated safe briefing / muster area. When instructed, begin check of mud for ph and H2S level. (Garett gas train.)
Safety personnel:	1.	Mask up and check status of all personnel and secure operations as instructed by drill site manager.

### <u>Taking a kick</u>

,

.

When taking a kick during an H2S emergency, all personnel will follow standard Well control procedures after reporting to briefing area and masking up.

### **Open-hole logging**

All unnecessary personnel off floor. Drill Site Manager and safety personnel should monitor condition, advise status and determine need for use of air equipment.

#### **Running casing or plugging**

Following the same "tripping" procedure as above. Drill Site Manager and safety personnel should determine if all personnel have access to protective equipment.

#### **Ignition procedures**

The decision to ignite the well is the responsibility of the operator (Oxy Drilling Management). The decision should be made only as a last resort and in a situation where it is clear that:

- 1. Human life and property are endangered.
- 2. There is no hope controlling the blowout under the prevailing conditions at the well.

#### Instructions for igniting the well

- 1. Two people are required for the actual igniting operation. They must wear self-contained breathing units and have a safety rope attached. One man (tool pusher or safety engineer) will check the atmosphere for explosive gases with the gas monitor. The other man is responsible for igniting the well.
- 2. Primary method to ignite: 25 mm flare gun with range of approximately 500 feet.
- 3. Ignite upwind and do not approach any closer than is warranted.
- 4. Select the ignition site best for protection, and which offers an easy escape route.
- 5. Before firing, check for presence of combustible gas.
- 6. After lighting, continue emergency action and procedure as before.
- 7. All unassigned personnel will remain in briefing area until instructed by supervisor or directed by the Drill Site Manager.

**<u>Remember</u>**: After well is ignited, burning hydrogen sulfide will convert to sulfur dioxide, which is also highly toxic. **<u>Do not assume the area is safe after the well is</u> ignited.** 

### Status check list

Note: All items on this list must be completed before drilling to production casing point.

- 1. H2S sign at location entrance.
- 2. Two (2) wind socks located as required.
- 3. Four (4) 30-minute positive pressure air packs (2 at each Briefing area) on location for all rig personnel and mud loggers.
- 4. Air packs inspected and ready for use.
- 5. Cascade system and hose line hook-up as needed.
- 6. Cascade system for refilling air bottles as needed.
- 7. Condition flag on location and ready for use.
- 8. H2S detection system hooked up and tested.
- 9. H2S alarm system hooked up and tested.
- 10. Hand operated H2S detector with tubes on location.
- 11. 1 100' length of nylon rope on location.
- 12. All rig crew and supervisors trained as required.
- 13. All outside service contractors advised of potential H2S hazard on well.
- 14. No smoking sign posted and a designated smoking area identified.
- 15. Calibration of all H2S equipment shall be noted on the IADC report.

Checked by:\_\_\_\_\_ Date:\_\_\_\_\_

### Procedural check list during H2S events

#### Perform each tour:

- 1. Check fire extinguishers to see that they have the proper charge.
- 2. Check breathing equipment to ensure that it in proper working order.
- 3. Make sure all the H2S detection system is operative.

#### Perform each week:

- 1. Check each piece of breathing equipment to make sure that demand or forced air regulator is working. This requires that the bottle be opened and the mask assembly be put on tight enough so that when you inhale, you receive air or feel air flow.
- 2. BOP skills (well control drills).
- 3. Check supply pressure on BOP accumulator stand by source.
- 4. Check breathing equipment mask assembly to see that straps are loosened and turned back, ready to put on.
- 5. Check pressure on breathing equipment air bottles to make sure they are charged to full volume. (Air quality checked for proper air grade "D" before bringing to location)
- 6. Confirm pressure on all supply air bottles.
- 7. Perform breathing equipment drills with on-site personnel.
- 8. Check the following supplies for availability.
  - A. Emergency telephone list.
  - B. Hand operated H2S detectors and tubes.

### General evacuation plan

- 1. When the company approved supervisor (Drill Site Manager, consultant, rig pusher, or driller) determines the H2S gas cannot be limited to the well location and the public will be involved, he will activate the evacuation plan.
- 2. Drill Site Manager or designee will notify local government agency that a hazardous condition exists and evacuation needs to be implemented.
- 3. Company or contractor safety personnel that have been trained in the use of H2S detection equipment and self-contained breathing equipment will monitor H2S concentrations, wind directions, and area of exposure. They will delineate the outer perimeter of the hazardous gas area. Extension to the evacuation area will be determined from information gathered.
- 4. Law enforcement personnel (state police, police dept., fire dept., and sheriff's dept.) Will be called to aid in setting up and maintaining road blocks. Also, they will aid in evacuation of the public if necessary.
- 5. After the discharge of gas has been controlled, company safety personnel will determine when the area is safe for re-entry.

<u>Important:</u> Law enforcement personnel will not be asked to come into a contaminated area. Their assistance will be limited to uncontaminated areas. Constant radio contact will be maintained with them.

#### **Emergency** actions

#### <u>Well blowout – if emergency</u>

- 1. Evacuate all personnel to "Safe Briefing / Muster Areas" or off location if needed.
- 2. If sour gas evacuate rig personnel.
- 3. If sour gas evacuate public within 3000 ft radius of exposure.
- 4. Don SCBA and shut well in if possible using the buddy system.
- 5. Notify Drilling Superintendent and call 911 for emergency help (fire dept and ambulance) if needed.
- 6. Implement the Blowout Contingency Plan, and Drilling Emergency Action Plan.
- 6. Give first aid as needed.

#### Person down location/facility

- 1. If immediately possible, contact 911. Give location and wait for confirmation.
- 2. Don SCBA and perform rescue operation using buddy system.

#### Toxic effects of hydrogen sulfide

Hydrogen sulfide is extremely toxic. The acceptable ceiling concentration for eight-hour exposure is 10 ppm, which is .001% by volume. Hydrogen sulfide is heavier than air (specific gravity -1.192) and colorless. It forms an explosive mixture with air between 4.3 and 46.0 percent by volume. Hydrogen sulfide is almost as toxic as hydrogen cyanide and is between five and six times more toxic than carbon monoxide. Toxicity data for hydrogen sulfide and various other gases are compared in table i. Physical effects at various hydrogen sulfide exposure levels are shown in table ii.

Table i		
<b>Toxicity</b>	of various	gases

Common name	Chemical formula	Specific gravity	Threshold limit	Hazardous limit	Lethal concentration (3)
		(sc=1)	(1)	(2)	
Hydrogen Cyanide	Hcn	0.94	10 ppm	150 ppm/hr	300 ppm
Hydrogen Sulfide	H2S	1.18	10 ppm	250 ppm/hr	600 ppm
Sulfur	So2	2.21	5 ppm	-	1000 ppm
Dioxide					
Chlorine	Cl2	2.45	l ppm	4 ppm/hr	1000 ppm
Carbon	Co	0.97	50 ppm	400 ppm/hr	1000 ppm
Monoxide					
Carbon	Co2	1.52	5000 ppm	5%	10%
Dioxide			FF		
Methane	Ch4	0.55	90,000 ppm	Combustibl	e above 5% in air

Methane Ch4 0.55 90,000 ppm Combustible above 5%

1) threshold limit – concentration at which it is believed that all workers may be repeatedly exposed day after day without adverse effects.

- 2) hazardous limit concentration that will cause death with short-term exposure.
- 3) lethal concentration concentration that will cause death with short-term exposure.

#### Toxic effects of hydrogen sulfide

### Table ii Physical effects of hydrogen sulfide

		<b>Concentration</b>	Physical effects
Percent (%)	<u>Ppm</u>	Grains	
		<u>100 std. Ft3*</u>	
0.001	<10	00.65	Obvious and unpleasant odor.

0.002	10	01.30	Safe for 8 hours of exposure.
0.010	100	06.48	Kill smell in $3 - 15$ minutes. May sting eyes and throat.
0.020	200	12.96	Kills smell shortly; stings eyes and throat.
0.050	500	32.96	Dizziness; breathing ceases in a few minutes; needs prompt artificial respiration.
0.070	700	45.36	Unconscious quickly; death will result if not rescued promptly.
0.100	1000	64.30	Unconscious at once; followed by death within minutes.

.

\*at 15.00 psia and 60'f.

. •

-

### Use of self-contained breathing equipment (SCBA)

- 1. Written procedures shall be prepared covering safe use of SCBA's in dangerous atmosphere, which might be encountered in normal operations or in emergencies. Personnel shall be familiar with these procedures and the available SCBA.
- 2 SCBA's shall be inspected frequently at random to insure that they are properly used, cleaned, and maintained.
- 3. Anyone who may use the SCBA's shall be trained in how to insure proper facepiece to face seal. They shall wear SCBA's in normal air and then wear them in a test atmosphere. (note: such items as facial hair {beard or sideburns} and eyeglasses will not allow proper seal.) Anyone that may be reasonably expected to wear SCBA's should have these items removed before entering a toxic atmosphere. A special mask must be obtained for anyone who must wear eyeglasses or contact lenses.
- 4. Maintenance and care of SCBA's:
  - a. A program for maintenance and care of SCBA's shall include the following:
    - 1. Inspection for defects, including leak checks.
    - 2. Cleaning and disinfecting.
    - 3. Repair.
    - 4. Storage.
  - b. Inspection, self-contained breathing apparatus for emergency use shall be inspected monthly.
    - 1. Fully charged cylinders.
    - 2. Regulator and warning device operation.
    - 3. Condition of face piece and connections.
    - 4. Rubber parts shall be maintained to keep them pliable and prevent deterioration.
  - c. Routinely used SCBA's shall be collected, cleaned and disinfected as frequently as necessary to insure proper protection is provided.
- 5. Persons assigned tasks that requires use of self-contained breathing equipment shall be certified physically fit (medically cleared) for breathing equipment usage at least annually.
- 6. SCBA's should be worn when:
  - A. Any employee works near the top or on top of any tank unless test reveals less than 10 ppm of H2S.

- B. When breaking out any line where H2S can reasonably be expected.
- C. When sampling air in areas to determine if toxic concentrations of H2S exists.
- D. When working in areas where over 10 ppm H2S has been detected.
- E. At any time there is a doubt as to the H2S level in the area to be entered.

#### <u>Rescue</u> First aid for H2S poisoning

#### Do not panic!

Remain calm – think!

- 1. Don SCBA breathing equipment.
- 2. Remove victim(s) utilizing buddy system to fresh air as quickly as possible. (go up-wind from source or at right angle to the wind. Not down wind.)
- 3. Briefly apply chest pressure arm lift method of artificial respiration to clean the victim's lungs and to avoid inhaling any toxic gas directly from the victim's lungs.
- 4. Provide for prompt transportation to the hospital, and continue giving artificial respiration if needed.
- 5. Hospital(s) or medical facilities need to be informed, before-hand, of the possibility of H2S gas poisoning no matter how remote the possibility is.
- 6. Notify emergency room personnel that the victim(s) has been exposed to H2S gas.

Besides basic first aid, everyone on location should have a good working knowledge of artificial respiration.

Revised CM 6/27/2012